



The Caldwell Group, Inc.

5055 26th Avenue (815) 229-5667
 Rockford, IL 61109 Toll Free (800) 628-4263
www.caldwellinc.com Fax (815) 229-5686

INSTRUCTION MANUAL FOR Model 16 Adjustable Spreader/Lifting Beam

Your new Model 16 Adjustable Spreader/Lifting Beam only supports loads up to its rated capacity when loaded correctly. The Model 16 is a load supporting lifter complying with ASME B30.20 BTH-1 Design Category B and Service Class 2, which is for specific tasks withstanding forces based on the unit's rated capacity. Use the following guidelines for your protection and for optimal operation of your equipment. The safety precaution list below is not necessarily all-inclusive. The owner/user is responsible for understanding and acting in accordance with ASME, ANSI, OSHA, local, and state regulations. Refer to the Manufacturer's Instruction Manual for product and safety information on other attachments, components, or both used with your lifting equipment.

1. **DO NOT EXCEED RATED CAPACITY.**
2. **DO NOT** lift or support people.
3. **DO NOT** lift over people.
4. **DO NOT** lift higher than necessary.
5. **DO NOT** leave suspended load unattended.
6. **DO** inspect the lifter for damage or excess wear before each use. Check for structural bending and cracks, excess wear at load points and pins, cracked or broken welds, or deformed hardware. If inspection reveals any defect(s), remove the lifting device from service, and tag "Out of Service". Immediately, notify your Safety Administrator or Supervisor to contact The Caldwell Group regarding any defect.
7. **DO** contact The Caldwell Group to replace worn or damaged tags and/or decals.

Lifting Operation

1. Know the rated capacity and weight of your Model 16 Adjustable Spreader/Lifting Beam (See the Caldwell Nameplate/ID tag on your lifting unit).
2. Use as 2, 3, or 4 point lifting, or spreader beam (See Figure 3, 4, and 5 for point lifting).
3. Prevent tilting of the Lifting Beam and load, by positioning the load's center of gravity in-line with the center of the crane hook.
4. Perform a test lift of several inches to verify the load is properly balanced and the beam is level/horizontal.
5. **See Figure 1**, the Lifting Beam is level/horizontal, proper lifting position.
6. **See Figure 2**, the Lifting Beam is not level/horizontal, improper lifting position.




Figure 1




Figure 2



Figure 3




Figure 4




Figure 5



The Caldwell Group, Inc.

5055 26th Avenue

Rockford, IL 61109


www.caldwellinc.com

(815) 229-5667

Toll Free (800) 628-4263

Fax (815) 229-5686

Model 16 Adjustable Spreader/Lifting Beam Tag & Decal Location



Model Number _____

Rated Capacity _____

Unit Weight _____