



Instructions, Parts and Maintenance Manual

AIR WINCH MODEL K5U & K5UL

Warning!

Review “WINCH OPERATING PRACTICES” Prior to use.

Always operate, inspect and maintain this winch in accordance with American National Standards Institute Safety Code (ANSI B30.7) and any other applicable safety codes and regulations.

This winch is only a component of the lifting system, which must be designed by qualified personnel

TABLE OF CONTENTS

Warning Tags
Safety Guidelines
Winch Operating Practices

1.0 General Information

1.1 User Responsibility and Safety Precaution

1.2 Introduction

- 1.2.1 Purpose
- 1.2.2 Model Number, Serial Number, and Options
- 1.2.3 Warranty

1.3 Equipment Description

- 1.3.1 Capabilities and Limitations
- 1.3.2 Specification and Descriptive Data

2.0 Functional Description

2.1 Major Assemblies

- 2.1.1 Drive Assemblies

3.0 Installation Instructions

3.1 Site Selection

3.2 Handling

3.3 Installation Procedures

- 3.3.1 Welding/Bolt Down
- 3.3.2 Requirements Prior to Start Up

3.4 *Installation Checkout*

- 3.4.1 Phase-1 Installation Inspection
- 3.4.2 Phase-2 Start Up and Preliminary Test

3.5 *Cable Installation*

- 3.5.1 Cable Termination on Drum
- 3.5.2 Spooling Cable onto Drum

4.0 *Operating Instructions*

- 4.1 Operator Start Up
- 4.2 Shutdown
- 4.3 Brake Release Valve

5.0 *Preventive Maintenance*

5.1 *Introduction*

- 5.2 Maintenance Plan
- 5.2.1 Lubrication Schedule
- 5.2.2 Cleaning
- 5.2.3 Cable and Hoses
- 5.2.4 Brake Adjustment
- 5.2.5 General Inspection
- 5.2.6 Bushing Replacement

6.0 *Component Removal/Replacement*

Appendices

Personnel Rating Performance Characteristics
K5U Utility Rating Performance Characteristics
K5U General Assembly Drawing
K5U Air Motor Assembly Drawing
K5U Air Motor Parts List
K5U Parts Illustration Sheet 1
K5U Parts Illustration Sheet 2
K5U Remote Control Parts Illustration
K5U Drum Guard Arrangement Drawing
K5U Parts List

WARNING TAG

Read the latest edition of ASME B30.7. Comply with all Federal, State and local rules.

It is the customer's responsibility to use this winch with adequate factors of safety for the rated load, plus the weight of the winch and attached equipment.

A registered structural engineer should review handling procedures.

! WARNING !

Failure to follow these warnings may result in death, severe injury or property damage:

- *Do not operate this winch before reading the operation and maintenance manual.*
- *Do not lift more than rated load.*
- *Do not allow less than three wraps of wire rope to remain on drum at all times. Operator must stay in view of the winch drum at all times to ensure this.*
- *Do not operate a damaged or malfunctioning winch.*
- *Do not remove or obscure warning labels.*
- *Any labels that become obscured or removed should be replaced as soon as possible.*

GENERAL GUIDELINES FOR SAFE OPERATION

The following warnings and precautions should be taken to ensure safe operating conditions.

Failure to remain alert and keep equipment in good operating condition could result in personal injury or death. To avoid such please read and understand this manual as well as all applicable laws and requirements for safe operation.

Keep a copy of this manual with the equipment at all times.

Be certain all operators of the equipment have been properly trained in the use of the equipment and have read the owners manual thoroughly.

!!WARNING!!

Keep hands, feet and any loose clothing away from rotating or moving parts. Never operate the equipment with any guards or safety equipment removed from winch. Failure to do so may result in injury or death.

When maintaining the equipment be sure to tag *Out of Service* on power supply to prevent accidental operation or activation.

Do not alter or modify the equipment in any way without first contacting RAM Winch & Hoist Engineering Department as to the alteration type or extent. Failure to do so could result in damage to the equipment or injury to personnel.

WINCH OPERATING PRACTICES

1. Read the manufacturer's instructions before operating the winch.
2. Always inspect, test maintain and operate this winch in accordance with American National Standards Institute Safety Standards B30.7.
3. Never Lift a load greater than the rated line pull of the winch.
4. Use the recommended size wire rope for load to be handled.
5. Never use the wire rope as a sling.
6. Always stand clear of the load.
7. Unless the winch is designed for personnel handling, never use this winch for lifting or lowering people, and never stand on a suspended load.
8. Never carry loads over people.
9. Never disengage the clutch with a load applied to the winch.
10. Never engage the clutch with the winch motor running.
11. Always rig the winch properly and carefully, making certain the wire rope is properly anchored to the drum.
12. Before each shift, check the winch for wear or damage. Check the brakes, wire rope, hooks, guides, mounting bolts, etc. Lift a capacity load or a near capacity load a few inches off the floor and check the ability of the braking system to stop and hold the load without excessive drift, if the winch is being used for lifting.
13. Never operate a winch with a twisted, kinked or damaged wire rope.
14. Periodically inspect the winch thoroughly and replace worn or damaged parts. Keep accurate records of all inspections and repairs.
15. Follow the lubrication instructions provided by the manufacturer.
16. Do not attempt to repair the wire rope or hooks. Replace hooks when there is a 15% increase in the throat opening or when there is a 10% bend as shown by inspection records.
17. Keep the rope clean and well lubricated. Replace wire rope that is frayed.
18. Ease the slack out of the wire rope when starting. Do not jerk the winch.
19. If the drum is exposed to personnel walkways, place a guard over the drum.
20. Do not use your hands to guide the rope onto the drum when winding in the wire rope.
21. Be certain there are no objects in the way of the load or hook when operating the winch.
22. Do not use higher air pressure than recommended by the manufacturer.
23. Use compressed air carefully. Be sure the hose couplings are secure, and make certain a safety chain is provided to avoid hose whip if the coupling fails.
24. Wear proper clothing to avoid entanglement in rotating machinery.
25. Be certain the air supply is shut off before performing maintenance on the winch.
26. Properly secure a winch before leaving it unattended.
27. Do not leave a load suspended for any extended period of time. Never leave a suspended load unattended.
28. Do not allow unqualified personnel to operate a winch.
29. Do not operate a winch if you are not physically fit to do so.
30. Do not divert your attention from the load while operating a winch.
31. Be certain the load is properly seated in the saddle of the hook. Do not tip load the hook as this leads to spreading and eventual failure of the hook.
32. Do not force a hook into place by hammering.
33. Never operate a winch beyond the point where less than four wraps of wire rope remain on the drum.
34. Do not use the wire rope as a ground for welding. Do not attach a welding electrode to a winch or sling.
35. Never operate a winch that makes excessive mechanical noise. Report the problem immediately.

Post at Operating Station

1.0 **General Information**

1.1 **User Responsibility and Safety Precautions**

This equipment will perform in conformity with the description thereof, contained in this manual, its accompanying labels and/or inserts when it is installed, operated, maintained and repaired according to the instructions provided. This equipment must be checked periodically.

Deficient equipment should not be used. Parts that are broken, missing, plainly worn, distorted or contaminated should be replaced immediately. Should such repair or replacement become necessary, we recommend that a telephone or written request for service be made to **RAM Winch & Hoist**.

This equipment or any of its parts should not be altered without prior written approval of **RAM Winch & Hoist**. The user of this equipment shall have the sole responsibility for any malfunction that results from improper use, faulty maintenance, damage, improper repairs or alterations made by anyone other than **RAM Winch & Hoist**.

1.2 **Introduction**

1.2.1 **Purpose**

The purpose of this manual is to provide operating instructions and maintenance procedures for your **RAM Winch & Hoist** Air Winch.

1.2.2 **Model Number, Serial Number and Options**

This manual covers the winch built by **RAM Winch & Hoist** for your particular unit. The model number and serial number are listed on the nameplate attached to the unit.

1.2.3 **Warranty**

See standard warranty certificate.

1.3 **Equipment Description**

1.3.1 **Capabilities and Limitations**

The winch is an air, gear reducer driven cable-handling unit with manual release or auto release band brake designed for use in the marine or industrial environment.

1.3.2 Specification and Descriptive Data

Working Line Pull 5,000 lbs. SWL mid-drum at 90 psig(utility rating).

!! WARNING !!

Exceeding recommended operating pressure of 90 psig might result in damage to winch and severe injury or death to personnel.

Cable Capacity See performance charts

Line Speed The line speed is variable from creep to full speed, see performance charts

Construction All steel with steel hardware.

Finish Sandblasted to near white metal. Primer coated with inorganic zinc to 2-3 mils DFT. Top coated with Carboline marine coating system.

Bearings See winch parts list and illustration drawing.

Drive System A piston-type air motor, coupled to a spur gear reducer.

Controls Integral to air motor. (See winch parts illustration drawing.)

Braking System Manually operated band brake type or spring applied pressure release auto band brake.

!! WARNING !!

Do not leave loads suspended on winch without operator present. Do not manually release the brake if a load is held suspended by the winch without operator or trained personnel present.

Performance Bare drum rating as indicated on winch nameplate is the maximum allowable load.

2.0 Functional Description

2.1 Major Assemblies

The winch consists of the following major assemblies:

- a. Drive assembly
- b. Frame and drum assembly

2.1.1 Drive Assemblies

The drive assemblies consist of:

- a. Air motor to gear reducer assembly
- b. Gear reducer to drum assembly

3.0 Installation Instructions

3.1 Site Selection

The winch should be installed in a location that meets the following requirements:

- ⇒ Firm foundation that allows the unit to be welded or bolted down to withstand a minimum of 5 times the maximum winch line pull.
- ⇒ Accessibility for the operator.
- ⇒ Protection from heavy falling objects.
- ⇒ Near an adequate air supply source.
- ⇒ As far as possible from the first turn sheave.
- ⇒ Out of the way of other operations.

3.2 Handling

Lifting the unit with a soft strap on drum or under the frame structure will accommodate standard lifts.

3.3 Installation Procedures

3.3.1 Welding / Bolting Down

When the winch is at or near the desired location, remove the shipping protection and position it exactly. If the winch is to be welded down, a qualified welder should be used. All exposed metal surfaces should be painted immediately after welding to inhibit rust.

You must have a qualified engineer determine the amount of weld required to securely hold the winch. If the unit is bolted down, be sure to use the proper size and a minimum of Grade 5 bolts and torque to the proper setting.

7/8-9 UNC Diameter SAE Grade 5 Bolts (Quantity 6)

| Torque Values | |
|---------------|--------------------|
| Dry Threads | Lubricated Threads |
| 430 ft-lbs | 260 ft-lbs |

These specifications are the recommended assembly torque for grade 5 threaded fasteners with the following qualifications:

1. The torque values shown are for turning the NUT while holding the head of the bolt with a wrench. If the application demands tightening by the bolt head, increase the value shown by 20% (multiple by 1.20). This will allow for the natural torsional twist of the bolt shank.
2. Torque values are calculated at 75% of proof load. This provides a safety factor.
3. All dry torque values are based on the use of through hardened flat washers.
4. Lubricated torque values are calculated based on applying Anti-Seize Compound to the threads before assembly.

The above specifications are referenced from the following organizations: SAE, ASTM, General Motors, Military and Federal Standards.

**** CAUTION ****

Extreme care should be taken to ensure the center of the winch drum exactly perpendicular to the cable running to the first sheave. This can be done by average sightings along the flat surface of the winch sidewall, drum flanges or with the help of a square to find the true perpendicular centerline. If it is not properly aligned, cable-laying problems may create difficulties and possibly damage the cable, winch and/or personnel.

3.3.2 Requirements Prior to Start Up

Fill air motor to proper level with oil. Be certain all hoses and fittings are tightened and not leaking. *See Section 5.0 Preventative Maintenance for Lubrication Schedule.* Check lubricator on air supply line for proper oil level. If low, then fill with 30-wt. oil.

3.4 Installation Checkout

3.4.1 Phase 1 - Installation Inspection

- ⇒ Check all bolts and fasteners to ensure that they are tightened properly.
- ⇒ Grease all bearings.
- ⇒ Test manual brake release / set with no load on the drum to ensure operating properly.

WARNING: *Lubricate the motor before operating the winch.* To avoid leakage during shipment the oil is drained from the motor. A sufficient quantity of oil for filling each unit is packed with the winch. Make certain the proper lubricant is used for each unit. Make certain the oil level plugs and drain plugs are securely threaded in place. Remove the vent cap and oil level plug. Pour the recommended oil into the motor case until it starts to come out the level plug hole. Replace the level plug and vent cap.

3.4.2 Phase 2 - Start Up and Preliminary Tests

- ⇒ Leaks - All fittings and hoses have been inspected for leaks at the factory prior to shipment. If leakage is noticed, tighten or replace as required to correct.
- ⇒ Using correct valve, operate unit to rotate drum and inspect for automatic brake release and free movement of the drum.

3.5 Cable Installation

3.5.1 Cable Termination on Drum

A cable lead-in hole is in the drum to allow termination. There are two (2) set screws placed in the drum feed thru hole to constrain the cable.

**** CAUTION ****

The set screws are not intended to take a full line pull on the cable. Three or more full wraps of cable must remain on the drum at all times and at any load case.

3.5.2 Spooling Cable onto Drum

Bring the cable under/over the drum and through the slot in the drum wall. Position the cable through the hole and secure the set screws. Handling and wrapping cable on the drum must be attended by a gloved operator to make certain that the cables lie on the drum properly.

The cable must not stack up above the drum flanges or it will fall off the side of the drum and possibly damage the cable. Whenever the equipment is being raised, the winch operator must watch for the end of the cable markings or the equipment itself. Before the equipment gets near the sheave, the operator should stop the winch.

**** CAUTION ****

Spooling of the cable must be done very carefully. To prevent injury, keep hands, clothing and anything that could catch on or get caught in the cable clear when the drum is rotating. This would pull the item or person into the cable spooling on the drum. Since spooling of the cable requires at least two people, an operator and someone to guide and control the cable, they must stay alert and maintain visual contact with each other at all times. We strongly recommend qualified and experienced personnel complete this procedure.

For units with Levelwind, refer to spooling device instructions.

4.0 Operating Instructions

4.1 Operator Start Up

- ⇒ Ensure the control valve handle is in mid position.
- ⇒ Check that the air supply is on and functioning properly.
- ⇒ Open the band brake if the unit has one. If brake is automatic then normal operation of control handle will operate brake.
- ⇒ Move the control valve handle in the direction of desired operation (payout/retrieve).

When lifting loads, the band brake should be used to help secure the load after lifting.

When lowering the load, the control valve should be operated in the payout direction slightly while loosening the band brake. The band brake will help control the descent rate by the amount of drag allowed.

4.2 Shutdown / Turn Off

- ⇒ Release winch control handle (The valve handle should return to center or neutral positions.)
- ⇒ Shut off air supply.

⇒ Tighten band brake.

⇒ Do not shut the unit down with a suspended load that relies on the winch as the only support.

4.3 **Brake Release Valve (If Auto Band Brake is supplied)**

The brake release valve operates from the Reverse Valve Spool. When the control valve handle is shift off center, pilot air is allowed to flow out to the brake for release. When the handle is returned to neutral or center position, pilot air is shut off and allows pilot release pressure to dump or exhaust, allowing the brake to set.

There is a bleeder valve adjustment on the side of the housing that holds the release valve. The valve is set at the factory, but after time and with continuous use, the valve may require some adjustment. This bleeder valve sets the rate at which the brake is released. This gives the winch precise spotting control in the payout mode with rated load.

When the valve handle is in the center position, there should be no air coming out of the release valve to the brake. If there is even a small amount going to the brake, this will prevent the quick exhaust from exhausting the brake air and allowing the brake to set. This is trial and error and should be done in small increments. If it is adjusted too far, the brake will not release or will release too fast.

5.0 **Preventative Maintenance**

5.1 **Introduction**

This section gives necessary information for periodic and preventive maintenance, and for some repairs or replacements. For further information, service assistance or problems, call **RAM Winch & Hoist** Service Department.

5.2 **Maintenance Plan**

5.2.1 **Lubrication Schedule**

Under normal operating conditions on a permanent installation, the following lubrication schedule is recommended:

1. The gear reducer is filled with grease (Lubriplate 1300AA) at the factory. After 500 hours of operation, remove 1 ¼" plug on gear case and check. If unit needs more grease then add thru this hole.
2. Lubricate the bearings with Lubriplate 130AA or equivalent at 50 hour intervals.
3. **Motor Lubrication**

Check oil daily and maintain level with opening in the side of the motor case. If the winch is being used more than four (4) hours per day, it may be necessary to check the level more often.

When the winch is subject to temperatures above freezing: After the winch has been idle for several hours or overnight, loosen the drain plug located at the bottom of the motor case and allow the accumulated water to drain out. After draining the water, tighten the plug in the bottom and remove a similar plug on the side of the motor case. Unscrew the vent cap and pour a sufficient quantity of the recommended oil through this opening to bring the oil level up to the side opening.

When the winch is subject to freezing temperatures: Allow the winch to remain idle long enough for the water content in the motor case to separate from the oil, but not long enough for it to freeze. Drain the water and replenish the oil as above. Should this procedure be impractical, drain the entire contents for the motor case immediately after operation ceases, and pour the oil back into the motor case before resuming operation. If not drained, a sufficient quantity of water will eventually accumulate and the oil splasher will freeze fast.

For temperatures 30° to 80°F (-1.1° to 26.6°C) use SAE 20 or 20W motor oil.

For temperatures below 30°F (-1.1°C) use SAE 10 or 10W motor oil.

For temperatures below 80°F (26.6°C) use SAE 30 motor oil.

**** CAUTION ****

DO NOT LUBRICATE WHILE UNIT IS OPERATING

4. Check the air supply lubricator prior to running and during operation. Do not operate without oil in the lubricator as this may damage the air motor. The lubricator should be set at about 10-15 drops per minute.

LUBRICATION SCHEDULE

| LOCATION | TYPE OF LUBRICANT | REPLACEMENT SCHEDULE |
|-----------------------|-------------------|------------------------------------|
| Gear Reducer | Grease | Once per Year |
| Air Motor | Oil SAE 30 Wt | As required by usage |
| Outboard Drum Bearing | Grease | Every 200 hours of operation |
| Air Motor Lubricator | Oil SAE 10 Wt | Daily or as required for heavy use |

5. Check oil weekly in the throttle valve, insert a small amount of grease into the Grease fittings (15), which is located on the Valve Chest (11). Use 1 to 2 strokes from a standard grease gun per fitting. Do not excessively grease, may cause damage to motor.

5.2.2 Cleaning

The winch will last longer and easier to maintain if it is kept relatively free of oil, dirt and rust. Rinsing as often as possible with fresh water will help minimize corrosion.

5.2.3 Cables and Hoses

All hose assemblies in service should be checked periodically for leaks, abrasions, kinks, cover blister or other damage. Assemblies showing signs of wear or damage must be replaced before they cause failure or create a hazard.

5.2.4 Brake Adjustment

To adjust the brake, remove the Brake Shoe Long Pin (131) and Brake Shoe Pin Cotter (132), rotate the Brake Adjusting Screw (130) into the Brake Yoke (129). Threading the screw into the yoke tightens the brake; backing the screw out of the yoke loosens the brake.

When replacing a Motor Shaft (76), press the damaged shaft from the Rope Drum (67) by inserting a suitable rod through the cored hole in the small-seal end of the rope drum. Press in the new shaft, wide-beveled end first, until the trailing face of the shaft is 2 49/64" from the face of the shaft boss in the rope drum.

When installing any needle-type Bearing (71, 79 or 80), always press the stamped end of the bearing shell.

5.2.5 General Inspection

Frequent inspections should be conducted if the winch is in consistent service. This should be done by operators or personnel trained or qualified to conduct safety, operation and maintenance inspections on the equipment. The equipment should be inspected quarterly for the following:

Fasteners

Check all bolts, nuts, springs, pins, screws, etc. Replace if worn, corroded or broken. Torque all bolts or nuts to proper values according to ASME standards.

Frames, Drum, Bracket and Base

The frames, drums, brackets and base should be inspected for deformation, cracks, corrosion, damage or wear. It may be necessary to disassemble the unit to find additional damage if there is deformation of the frames, base, drum, or flanges of the drum. Replace any of the above items if excessive wear is noticed.

Brakes

Replace the brake band if the lining is worn down to the head of the rivets. Failure to do so could result in a malfunction of the brake and possible damage to the winch, to personnel or to equipment.

Wire Rope

The wire rope should be inspected after each use. Inspect and replace according to the wire rope manufacturer's guidelines.

5.2.6 Bushing Replacement

To replace a Reverse Valve Bushing (14) or a Rotary Valve Bushing (13) use the following instructions:

1. Remove the Valve Chest Cover Cap Screws (18), Valve Chest Cap Screws (19) and Throttle Valve Cap (24).

2. Withdraw the Throttle Valve (21) and Throttle Ball (23). The Throttle Ball may be lifted out with a quantity of sticky grease placed on the end of a rod.
3. Withdraw the Reverse Valve (25) and Rotary Valve (26). A bolt can be threaded into the tapped hole in the valve face to serve as a handle. The Reserve Valve is tapped 1/2" - 13 thread. The Rotary Valve is tapped 5/8" - 11 thread.
4. Thread a HU-932 Valve Chest Jack Bolt, or any 5/8" - 11 thread bolt having at least 4" of thread into the tapped hole in the lug on each side of the Valve Chest (11). Thread the bolt until it contacts the Motor Case (1). Tighten each bolt a fraction of a turn at a time, until the Valve Chest is removed from the Motor Case.
5. Support the face of the Valve Chest that contacts the Motor Case; using an arbor that will clear the Bushings Keys (12), press out the old bushings.
6. Turn the Valve Chest over so that the face that contacts the Motor Case is up.
7. Align the groove in the new Reverse Valve Bushing with the Bushing Key that protrudes into the small bore of the Valve Chest, press in the new Bushing until its leading face is flush with the supported face of the Valve Chest.
8. Align the groove in the new Reserve Valve Bushing with the Bushing Key that protrudes into the large bore of the Valve Chest, press in the new Bushing until its leading face is flush with the supported face of the Valve Chest.
9. Insert the No. 49265 Throttle Valve Stem Reamer or a .627" diameter reamer into the throttle valve chamber and ream the hole through the bushing wall where the Throttle Valve Ball (23) operates.
10. Check the fit of the Reverse Valve (25) in the Reverse Valve Bushing. If tight, ream the Bushing 2.250". **Caution: The Reverse Valve is chrome plated; do not lap.**
11. Check the fit of the Rotary Valve in the Rotary Valve Bushing. If the Valve is tighter than a good fit, lap it in with a mild, fine-grain lapping compound. If the Valve is too tight to lap, ream the Bushing to 2.875".
12. Align the cam groove on the Reverse Valve with the hole through the wall of the Bushing where the Throttle Valve Ball operates.
13. Apply a few drops of light oil to the Throttle Valve Ball and to the stem of the Throttle Valve. Insert the Ball, Valve and Throttle Valve Spring (22) into the valve chamber and retain them with the Throttle Valve Cap (24).
14. Place the Throttle Lever Spring (37) on the Control Arm (29) so that the coil encircles the protruding hub. Rotate the Spring until its lower leg contacts the Throttle Spring Stop Pin (30) which projects from the Control Arm.

15. Install the Throttle Control Arm so that its square socket slides over the square shank of the Reverse Valve, and the Spring legs are on opposite sides of the Stop Pin on the Valve Chest.

6.0 **Component Removal / Replacement**

Maintenance of the winch consists of determining the defective part and removing and repairing or replacing that component. All work should be done only after the air supply is shut off and tagged *Out of Service*. If needed, consult with **RAM Winch & Hoist** or its nearest trained representative for service.

APPENDICES

Personnel Rating Performance Characteristics
K5U Utility Rating Performance Characteristics
K5U General Assembly Drawing
K5U Air Motor Assembly Drawing
K5U Air Motor Parts List
K5U Parts Illustration Sheet 1
K5U Parts Illustration Sheet 2
K5U Remote Control Parts Illustration
K5U Drum Guard Arrangement Drawing
K5U Parts List

RAM AIR WINCH PARTS

When ordering parts, please have the model number and serial number for your unit. If possible, please supply us with the original purchase order number.

See the following pages for part ordering information.

Please call (281) 999-8665 or fax an order to (281) 999-8666.

RAM

WINCH AND HOIST

Winch Design / Performance Characteristics

| Winch Model | | K5U | | | | | | | |
|---------------|---------------|---------------------------|----------------|---|----------------------------|-------------|------------------|------------------------|------------------------|
| Line Pull | 5000.0 | Line Speed | 129.0 | No. of Layers Flange Dia Drum Rpm No. of Wraps | MAX Hp Line pull (lbs.) | Speed (fpm) | Flange Clearance | Stall Line Pull (lbs.) | Start Line Pull (lbs.) |
| Wire Rope dia | 1/2 | Length, ft | 775 | | | | | | |
| K Factor | 0.9 | Drum Dia., in | 8.625 | | | | | | |
| Drum Width | 10.0 | | | | | | | | |
| Layer No. | Capacity (ft) | Accumulated Capacity (ft) | Pitch Dia (in) | | | | | | |
| 1 | 48 | 48 | 9.1 | 7374 | 87.5 | 4.7 | 13146 | 10271 | |
| 2 | 52 | 100 | 10.0 | 6735 | 95.8 | 4.3 | 12006 | 9380 | |
| 3 | 57 | 157 | 10.9 | 6197 | 104.1 | 3.8 | 11048 | 8631 | |
| 4 | 61 | 218 | 11.7 | 5739 | 112.4 | 3.4 | 10231 | 7993 | |
| 5 | 66 | 284 | 12.6 | 5344 | 120.7 | 3.0 | 9527 | 7443 | |
| 6 | 70 | 355 | 13.5 | 5000 | 129.0 | 2.5 | 8914 | 6964 | |
| 7 | 75 | 430 | 14.3 | 4698 | 137.3 | 2.1 | 8375 | 6543 | |
| 8 | 80 | 509 | 15.2 | 4430 | 145.6 | 1.7 | 7897 | 6169 | |
| 9 | 84 | 593 | 16.1 | 4190 | 153.9 | 1.2 | 7471 | 5836 | |
| 10 | 89 | 682 | 16.9 | 3976 | 162.2 | 0.8 | 7088 | 5538 | |
| 11 | 93 | 775 | 17.8 | 3782 | 170.5 | 0.6 | 6743 | 5268 | |

RAM WINCH AND HOIST

Winch Design / Performance Characteristics

| Winch Model | | K5U | | | | | | | | | |
|---------------|---------------|---------------------------|----------------|-----------------|-------------|------------------|------------------------|------------------------|--|--|--|
| Line Pull | 5000.0 | Line Speed | 129.0 | | | | | | | | |
| Wire Rope dia | 5/8 | Length, ft | 437 | No. of Layers | 8.0 | | | | | | |
| K Factor | 0.9 | Drum Dia., in | 8.625 | Flange Dia | 19.0 | | | | | | |
| Drum Width | 10.0 | | | Drum Rpm | 33.6 | | | | | | |
| | | | | No. of Wraps | 16 | | | | | | |
| Layer No. | Capacity (ft) | Accumulated Capacity (ft) | Pitch Dia (in) | MAX Hp | | Flange Clearance | Stall Line Pull (lbs.) | Start Line Pull (lbs.) | | | |
| | | | | Line pull (lbs) | Speed (fpm) | | | | | | |
| 1 | 39 | 39 | 9.3 | 7928 | 81.4 | 4.6 | 12969 | 10132 | | | |
| 2 | 43 | 82 | 10.3 | 7097 | 90.9 | 4.0 | 11609 | 9070 | | | |
| 3 | 48 | 130 | 11.4 | 6423 | 100.4 | 3.5 | 10508 | 8209 | | | |
| 4 | 52 | 182 | 12.5 | 5867 | 109.9 | 2.9 | 9597 | 7498 | | | |
| 5 | 57 | 239 | 13.6 | 5399 | 119.5 | 2.4 | 8832 | 6900 | | | |
| 6 | 61 | 301 | 14.7 | 5000 | 129.0 | 1.9 | 8179 | 6390 | | | |
| 7 | 66 | 366 | 15.7 | 4656 | 138.5 | 1.3 | 7617 | 5951 | | | |
| 8 | 71 | 437 | 16.8 | 4356 | 148.1 | 0.8 | 7127 | 5568 | | | |

RAM

WINCH AND HOIST


Winch Design / Performance Characteristics

| Winch Model | | K5UL | | | | | | |
|---------------|---------------|---------------------------|----------------|-----------------|-------------|------------------|------------------------|------------------------|
| Line Pull | 5000.0 | Line Speed | 129.0 | | | | | |
| Wire Rope dia | 1/2 | Length, ft | 1550 | No. of Layers | 11.0 | | | |
| K Factor | 0.9 | Drum Dia., in | 8.625 | Flange Dia | 19.0 | | | |
| Drum Width | 20.0 | | | Drum Rpm | 36.6 | | | |
| | | | | No. of Wraps | 40 | | | |
| Layer No. | Capacity (ft) | Accumulated Capacity (ft) | Pitch Dia (in) | MAX Hp | | Flange Clearance | Stall Line Pull (lbs.) | Start Line Pull (lbs.) |
| | | | | Line pull (lbs) | Speed (fpm) | | | |
| 1 | 96 | 96 | 9.1 | 7374 | 87.5 | 4.7 | 13146 | 10271 |
| 2 | 105 | 200 | 10.0 | 6735 | 95.8 | 4.3 | 12006 | 9380 |
| 3 | 114 | 314 | 10.9 | 6197 | 104.1 | 3.8 | 11048 | 8631 |
| 4 | 123 | 437 | 11.7 | 5739 | 112.4 | 3.4 | 10231 | 7993 |
| 5 | 132 | 568 | 12.6 | 5344 | 120.7 | 3.0 | 9527 | 7443 |
| 6 | 141 | 709 | 13.5 | 5000 | 129.0 | 2.5 | 8914 | 6964 |
| 7 | 150 | 859 | 14.3 | 4698 | 137.3 | 2.1 | 8375 | 6543 |
| 8 | 159 | 1018 | 15.2 | 4430 | 145.6 | 1.7 | 7897 | 6169 |
| 9 | 168 | 1187 | 16.1 | 4190 | 153.9 | 1.2 | 7471 | 5836 |
| 10 | 177 | 1364 | 16.9 | 3976 | 162.2 | 0.8 | 7088 | 5538 |
| 11 | 186 | 1550 | 17.8 | 3782 | 170.5 | 0.6 | 6743 | 5268 |

WINCH AND HOIST

RAM


Page 1



| DWG NO. | ITEM QTY | PART NO. | DESCRIPTION | MATL | WT. |
|---------|----------|----------|-------------|------|-----|
| | | | | | |

| | | | | |
|---|--|--|--|--|
| RAM WINCH HOIST P.O. BOX 62063 HOUSTON, TEXAS 77205 | | WINCH GENERAL ASSEMBLY K5U/K5UL | | REV: 0 DATE: 12/1/03 |
| CUSTOMER: CUSTOMER P.O. NO.: PROJECT: | | DRAWING NUMBER: S001353 | | REV: 0 DATE: 12/1/03 |
| TOLERANCE UNLESS OTHERWISE SPECIFIED: DEC .015 FRACTION 1/32 DEC .005 FRACTION 1/64 | | PANT SPEC. DEC .015 FRACTION 1/32 DEC .005 FRACTION 1/64 | | DO NOT SCALE DEC .015 FRACTION 1/32 DEC .005 FRACTION 1/64 |

THIS DRAWING IS THE PROPERTY OF RAM, INC. THE DESIGN AND THE MANUFACTURE OF THIS EQUIPMENT ARE THE SOLE PROPERTY OF RAM, INC. NO PART OF THIS EQUIPMENT MAY BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING, RECORDING, OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN PERMISSION OF RAM, INC. RAM, INC. ACCEPTS NO LIABILITY FOR ANY DAMAGE OR LOSS OF PROFITS, BUSINESS, OR REVENUE, OR FOR ANY SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, WHETHER IN A CONTRACT OR TORT, ARISING OUT OF OR FROM THE USE OF THIS EQUIPMENT.



REVISIONS
 DESCRIPTION
 DATE
 BY
 APPROVED FOR CONSTRUCTION
 DATE
 BY

DO NOT SCALE
 UNIT: IN
 MATERIAL
 13/1
 8/17/00


PAINT SPEC:
 UNFINISHED
 0.015
 8/17/00

RAMI, INC.
 P.O. BOX 62063
 HOUSTON, TEXAS 77205


Motor Parts Listing

| No. | Part Number | Qty. (each) | Description |
|-----|--------------|-------------|--|
| 1 | K5M-501 | 1 | Motor Case |
| 2 | D02-402 | 2 | Drain Plug |
| 3 | KU-888 | 1 | Motor Eyebolt (2 for K5U or K5UL) |
| 4 | E5UD-947 | 1 | 1-1/4" Pipe Plug for K5U or K5UL |
| 5 | D02-303A | 1 | Vent Cap |
| 6 | D02-421 | 1 | S-Hook |
| 7 | D02-891 | 1 | Vent Cap Chain |
| 8 | D02-889 | 1 | Vent Cap Screen |
| 9 | 6CND-233-1/2 | 1 | Vent Cap Screen Retainer |
| 10 | D02-893 | 1 | Vent Cap Cotter |
| 11 | KK5UM-545 | 1 | Valve Chest for K5U or K5UL |
| 12 | HU-538 | 2 | Bushing Key |
| 13 | K5M-525S | 1 | Rotary Valve Bushing |
| 14 | KU-945S | 1 | Reverse Valve Bushing |
| 15 | 23-188 | 2 | Grease Fitting |
| 16 | D02-553 | 1 | Throttle Lever Spring Stop Pin |
| 17 | D02-402 | 2 | Brake Inlet Plug |
| 18 | KU-546A | 1 | Valve Chest Cover |
| 19 | KU-548 | 4 | Valve Chest Screw |
| 20 | D10-322 | 4 | ½ Lock Washer |
| 21 | KU-940 | 1 | Poppet Throttle Valve |
| 22 | HU-942 | 1 | Poppet Throttle Valve Spring |
| 23 | D10-322 | 4 | Poppet Throttle Valve Ball |
| 24 | KU-943 | 1 | Poppet Throttle Valve Cap |
| 25 | KU-K744A | 1 | Reverse Valve for Winch with automatic brake |
| 26 | KU-526A | 1 | Rotary Valve for over winding Winch |
| 27 | KU-527 | 1 | Large Valve Drive Pin |
| 28 | HU-527 | 2 | Small Valve Driver Pin |
| 29 | KU-555A | 1 | Throttle Control Arm |
| 30 | D02-553 | 1 | Throttle Lever Spring Stop Pin |
| 31 | HU-556 | 1 | Throttle Lever |
| 32 | HU-869 | 1 | Throttle Lever Latch |
| 33 | HU-567 | 1 | Throttle Lever Latch Spring |
| 34 | HU-842 | 1 | Throttle Lever Set Screw |
| 35 | HU-870 | 1 | Throttle Lever Pin |
| 36 | D02-524 | 2 | Throttle Lever Pin Cotter |
| 37 | K6U-412 | 1 | Throttle Lever Spring |
| 38 | K5M-A516 | 1 | Crank Assembly for K5U or K5UL |


| | | | |
|----|--------------|---|--|
| 39 | KU-516 | 1 | Crank Bare (consists of 2 matched parts which are not sold separately) |
| 40 | KU-540 | 1 | Oil Splasher |
| 41 | KU-541 | 2 | Oil Splasher Long Rivet |
| 42 | KU-542 | 2 | Oil Splasher Short Rivet |
| 43 | KU-519 | 1 | Crank Pin Sleeve |
| 44 | KU-520 | 1 | Crank Lock Pin |
| 45 | D02-317 | 1 | Crank Lock Pin Nut |
| 46 | D02-330 | 1 | Crank Lock Pin Cotter |
| 47 | K5M-509 | 5 | Connecting Rod for K5U or K5UL |
| 48 | KU-510 | 2 | Connecting Rod Ring |
| 49 | KU-511 | 1 | Connecting Rod Bushing |
| 50 | KU-518 | 1 | Crank Valve End Bearing |
| 51 | KU-895 | 1 | Crank Pin End Bearing |
| 52 | KU-A505A | 1 | Cylinder Assembly (5 for K5U or K5UL) |
| 53 | PD5-H505A | 1 | Cylinder Head |
| 54 | KU-L505A | 1 | Cylinder Sleeve |
| 55 | K5W-A513A | 1 | Piston Ring (5 for K5U or K5UL) |
| 56 | KU-337-5 | 1 | Piston Ring (1 for each Piston) |
| 57 | KU-338-5 | 1 | Oil Regulating Ring (1 for each Piston) |
| 58 | ILA902A9-589 | 1 | Wrist Pin Retaining Ring (2 for each Piston) |
| 59 | K5W-514 | 1 | Piston Wrist Pin (5 for K5U or K5UL) |
| 60 | K5W-507 | 1 | Cylinder Gasket (5 for K5U or K5UL) |
| 61 | 215-13 | 1 | Cylinder Cap Screw (4 for each Cylinder) |
| 62 | KU-504 | 1 | Cylinder Cap Screw Washer |
| 63 | K5M-592 | 1 | Motor Case Gasket for K5U or K5UL |
| 64 | 215-36 | 1 | Cylinder Cap Screw (4 for each Cylinder) |
| 65 | A-67 | 1 | 5/8: Lock Washer (10 for K5U or K5UL) |
| 66 | K5W-99R | 1 | Motor Nameplate |
| 67 | R4K-302 | 4 | Nameplate Screw |
| 68 | DU-301R | 1 | Winch Nameplate |
| 69 | R4K-302 | 4 | Nameplate Screw |
| 70 | TA-147A | 1 | Caution Plate |
| 71 | R4K-302 | 4 | Caution Plate Screw |
| 72 | K5UR-553 | 2 | Throttle Lever Stop |
| | | | Page 2 of 2 |



PARTS ILLUSTRATION SHEET 1




Remote Control Block Assembly



Remote Control Valve Chest Assembly

REMOTE CONTROL PARTS ILLUSTRATION DRAWING



DRUM GUARD ARRANGEMENT DRAWING

K5U/K5UL PARTS LIST

| Item No. | Description of Part | Unit Total | Part Number |
|----------|------------------------------------|------------|-------------|
| 65 | Base | | |
| | For K5U | | K4U-564A |
| | For K5UL | | K4UL-564A |
| 67 | Rope Drum | | |
| | For K5U | | K5U-324 |
| | For K5UL | | K5UL-324 |
| 68 | Wire Rope Set Screws | 2 | 215-140 |
| 69 | Drum Shaft | | |
| | For K5U | | K4U-459 |
| | For K4UL-459 | | |
| * | Drum Shaft Oil Seal | 2 | K4UL-271 |
| 70 | Drum Packing | | 207-136 |
| 71 | Drum Bearing | 2 | K4U-466 |
| 73 | Drum Bearing Plate | 4 | K4U-469 |
| 74 | Drum Shaft Short Set Screw | | HU-867 |
| 75 | Drum Shaft Long Set Screw | | HU-868 |
| 76 | Motor Shaft | | K4UL-316C |
| | For K5U | | K4U-316C |
| | For K5UL | | K4UL-316C |
| 77 | Motor Pinion Key | | EEG-768 |
| 78 | Motor Shaft Pinion | | K4U-319B |
| 79 | Motor Shaft Bearing | | K4U-598B |
| * | Motor Shaft Bearing Seal | | R10V-310 |
| 80 | Intermediate Gear | | K4U-364 |
| 81 | Intermediate Gear Bushing | | K4U-363 |
| 82 | Intermediate Gear Bushing Retainer | | K4U-362 |
| 83 | Fiber Washer | | K4U-871 |
| 84 | Gear Case | | K4U-K353A |
| 85 | Gear Case Screw | 10 | 215-148 |
| 86 | Lock Wash | 10 | D10-322 |
| 87 | Gear Cover | | K4U-352 |
| 88 | Grease Fitting | | 23-188 |
| 89 | Drive Shaft | | K4U-358 |
| 90 | Clutch Jaw Lock Bail | | G601-65 |
| 91 | Clutch Jaw Lock Spring | | K4U-863 |
| 92 | Clutch Jaw Lock Plug | | HU-864 |
| ●93 | Drive Shaft Inner Bearing | | 2325-41 |
| ●94 | Drive Shaft Outer Bearing | | 215-52 |
| 95 | Clutch Jaw | | K4U-568 |
| 96 | Clutch Eccentric Shaft | | HU-K857 |
| 97 | Clutch Eccentric Roller | | HU-858 |
| 98 | Clutch Eccentric Pin | | HU-859 |

* Not Illustrated

● To keep downtime to a minimum, it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each part indicated by a bullet (●) for every four tools in service.

K5U/K5UL PARTS LIST

| Item No. | Description of Part | Unit Total | Part Number |
|----------|---|------------|-------------|
| 99 | Eccentric Pin Lock Screw | | HU-860 |
| 100 | Clutch Lever | | HU-565 |
| 101 | Clutch Latch | | HU-566 |
| 102 | Latch Spring | | HU-567 |
| 103 | Clutch Lever Pin | | HU-861 |
| 104 | Eccentric Shaft Lock Screw | | HU-865 |
| 105 | Base Bolt | 8 | K6U-775 |
| 106 | Base Bolt Nut | 8 | DU-562 |
| 107 | Base Bolt Lock Nut Washer | 8 | D01-692 |
| 108 | Grease Plug | 2 | 22SR-165 |
| 109 | 3/8" Lock Washer | | D02-321 |
| 110 | Drive Shaft Nut | | 215-73 |
| 111 | Drive Shaft Nut Lock | | 215-74 |
| 112 | Drum Bearing Retainer | 2 | K4U-340 |
| 115 | Brake Band Assembly | | K5U-A152A |
| 116 | Brake Lining | | K4U-K155 |
| 117 | Brake Lining Short Rivet | 16 | K4U-156 |
| 118 | Brake Lining Long Rivet | 17 | 235-98 |
| 119 | Brake Support Spring Bracket | | K4U-161A |
| 120 | Spring Bracket Rivet | 2 | 107-153 |
| ●121 | Brake Shoe (Not Sold Separately) | | |
| 122 | Brake Shoe Rivet | | |
| 123 | Brake Lever Bracket (Not Sold Separately) | | |
| 124 | Brake Lever Bracket Rivet | 5 | 107-153 |
| 125 | Brake Lining Long Rivet | 5 | 235-98 |
| ●126 | Brake Handle | | 107-151 |
| 127 | Brake Handle Pin | | 107-149 |
| 128 | Brake Handle Pin Cotter | 2 | 107-146 |
| 129 | Brake Yoke | | 107-159 |
| 130 | Brake Adjusting Screw | | 107-158 |
| 131 | Brake Shoe Long Pin | | 107-147 |
| 132 | Brake Shoe Pin Cotter | 2 | D02-330 |
| 133 | Brake Anchor | | K4U-206 |
| 134 | Brake Anchor Nut | | HU-776 |
| 135 | Brake Anchor Lock Washer | | A-67 |
| 136 | Brake Support Screw | | K4U-162 |
| 137 | Brake Support Screw Jam Nut | | G7-18 |
| 138 | Brake Support Screw Washer | | K4U-343 |
| 139 | Brake Support Spring | | T03-119 |

* Not Illustrated


● To keep downtime to a minimum, it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each part indicated by a bullet (●) for every four tools in service.

| Item No. | Description of Part | Unit Total | Part Number |
|----------|-------------------------|------------|-------------|
| 140 | Brake Lever Bracket Pin | | 107-148 |
| * | Bracket Pin Cotter | | 107-146 |
| * | Motor Nameplate | | K5W-99 |
| * | Nameplate Screw | 4 | R4K-302 |
| * | Winch Nameplate | | DU-301 |
| * | Nameplate Screw | 4 | R4K-302 |
| * | Caution Plate | | TA-147A |
| * | Caution Plate Screw | 4 | R4K-302 |
| | | | |

* Not Illustrated

● To keep downtime to a minimum, it is desirable to have on hand certain repair parts. We recommend that you stock one (pair or set) of each part indicated by a bullet (●) for every four tools in service.

DISC BRAKE ASSEMBLY DRAWING




(Dwg. MHTPA0152)

DISC BRAKE ASSEMBLY PARTS LIST

| ITEM NO. | DESCRIPTION OF PART | QUANTITY TOTAL | PART NUMBER | |
|----------|---|----------------|-------------|------------|
| | | | FA2 | FA2.5 |
| 1 | Capscrew (with Disc Brake) | See () | 51448 (5) | 51471 (8) |
| • 2 | Oil Seal | 1 | 52223 | 54463 |
| • 5 | 'O' Ring | 1 | 51484 | 51459 |
| 6 | Motor Adapter | 1 | 10361 | 14227 |
| 7 | Shaft Extender | 1 | 11104 | 10594 |
| 8 | Brake Reaction Plate | 1 | --- | 10597 |
| • 9 | Spring | See () | 50751 (12) | 50751 (15) |
| 10 | Brake Piston | 1 | 15453 | 15437 |
| • 11 | Seal | 1 | 51483 | 51462 |
| • 12 | Seal | 1 | 51482 | 51461 |
| 15 | Seal Adapter | 1 | --- | 16354 |
| • 16 | Friction Plate | See () | 51481 (2) | 50772 (3) |
| • 17 | Drive Plate | See () | 51480 (1) | 50773 (2) |
| 18 | Collar | 1 | --- | 71039333 |
| 19 | Splined Hub | 1 | 11136 | 10600 |
| 20 | Sleeve, Fitting | 2 | 55014 | |
| 21 | Brake Housing | 1 | 11324 | 11322 |
| 22 | Fitting | 1 | 51803 | |
| • 23 | Breather | 1 | 51857 | |
| 24 | Pipe Plug | 1 | 50801 | |
| 25 | Fitting | 1 | 52182 | |
| 26 | Elbow Fitting | 1 | 71056972 | |
| | Tee Fitting (for units with auto drum band brake and disc brake only) | 1 | 52181 | |
| 27 | Tubing | 1 | 52520 | |
| 28 | Nut, Fitting | 2 | 55013 | |
| 29 | Vented Fitting | 1 | 51814 | |
| • 30 | Dump Valve | 1 | 50276 | |
| 31 | Fitting | 1 | 51034 | 50859 |
| 32 | Retainer Ring | 1 | 52227 | 50904 |
| • 33 | 'O' Ring | 1 | 51460 | |
| 34 | Spacer | 1 | --- | 18683 |
| 35 | Shaft | 1 | 11095 | 10579 |

• Recommended spare.

DRUM BRAKE ASSEMBLY DRAWING




(Dwg. MHTPB0209)

DRUM BRAKE ASSEMBLY PARTS LIST

| ITEM NO. | DESCRIPTION OF PART | QUANTITY TOTAL | PART NUMBER | |
|----------|-------------------------------|----------------|--------------|-----------------|
| | | | MANUAL BRAKE | AUTOMATIC BRAKE |
| 80 | Drum (8 inch long) | 1 | 11354-1 | |
| | Drum (10 inch long) | | 11354-2 | |
| | Drum (16 inch long) | | 11354-3 | |
| | Drum (24 inch long) | | 11354-5 | |
| 101 | Pin | 2 | 4303-S | |
| 102 | Cotter Pin | See () | 51937 (5) | 51937 (7) |
| 103 | Link Stud | 1 | 2448 | |
| 104 | Handle | 1 | 2329 | --- |
| 105 | Brake Lever | 1 | --- | 11498 |
| 106 | Pin | 2 | --- | 8609 |
| 107 | Clevis | 1 | --- | 6237-2 |
| 108 | Nut | 1 | --- | 50159 |
| 109 | Breather | 1 | --- | 52384 |
| 110 | Cylinder | 1 | --- | 4575-1 |
| 111 | Fitting | 1 | --- | 52006 |
| • 112 | Dump Valve | 1 | --- | 51954 |
| 113 | Fitting | 2 | --- | 52385 |
| 114 | Elbow | 1 | --- | 52330 |
| 115 | Hose | 1 | --- | 50923 |
| 116 | Capscrew | 3 | --- | 50873 |
| 117 | Lockwasher | 3 | 50181 | |
| 118 | Bracket | 1 | --- | 11493 |
| 119 | Capscrew | 3 | 50973 | |
| 120 | Nut | See () | 50171 (1) | 50171 (2) |
| 121 | Pin | 3 | 3704-S | |
| 122 | Pivot Bracket | 1 | 11146 | |
| 123 | Washer | As Req'd | 50890 | |
| 124 | Arm | 1 | 11147 | |
| 125 | Connecting Link | 1 | 11144 | |
| 126 | Stop Plate | 1 | 11145 | |
| 127 | Screw | 1 | 52226 | |
| • 128 | Brake Band | 1 Set | 10724 (Set) | |
| | Brake Band Lining Kit | 1 Kit | 10724-BLK | |
| 129 | Washer | 5 | 52914 | |
| 130 | Side Rail (8 inch long drum) | 1 | 11357-1 | |
| | Side Rail (12 inch long drum) | | 11357-2 | |
| | Side Rail (16 inch long drum) | | 11357-3 | |
| | Side Rail (24 inch long drum) | | 11357-5 | |
| 131 | Side Rail (8 inch long drum) | 1 | 11358-1 | |
| | Side Rail (12 inch long drum) | | 11358-2 | |
| | Side Rail (16 inch long drum) | | 11358-3 | |
| | Side Rail (24 inch long drum) | | 11358-5 | |

• Recommended spare.

FA2 MOTOR ASSEMBLY DRAWING



(Dwg. MHTPB0210)


FA2 MOTOR ASSEMBLY PARTS LIST

| ITEM NO. | DESCRIPTION OF PART | QUANTITY TOTAL | PART NUMBER |
|----------|--|----------------|----------------------------|
| * | Motor Assembly | 1 | 50259-1 |
| • 2 | Oil Seal | 1 | 52223 |
| 6 | Motor Adapter | 1 | 10361 |
| 96 | Lockwasher | 5 | 50200 |
| 97 | Capscrew | 5 | 50829 |
| 363 | Lockwasher | 2 | 51486 |
| 364 | Capscrew | 2 | 54840 |
| 451 | Capscrew | 20 | 50871 |
| • 452 | Copper Washer | 1 Set | 94-027-20 |
| 453 | Cylinder | 5 | 94-024 |
| • 454 | Compression Ring | 5 | Order Kit 94-RS |
| 455 | Piston Assy (Incl's items 454, 457, & 458) | 5 | 94-010A |
| 456 | Plug | 10 | Order 94-011-1A (Item 457) |
| 457 | Wrist Pin Assembly (Incl's item 456) | 5 | 94-011-1A |
| • 458 | Oil Ring | 5 | Order Kit 94-RS |
| 459 | Connecting Rod | 5 | 94-009 |
| • 460 | Gasket | 1 Set | 94-025-5 |
| 462 | Vent Cap Assembly | 1 | 94-018 |
| 463 | Motor Housing | 1 | 94-014 |
| 464 | Pipe Plug | 2 | 94-015 |
| 465 | Bearing | 2 | 50944 |
| • 466 | Rotary Bushing | 1 | 10986 |
| • 467 | Rotary Valve | 1 | 94-019 |
| 468 | Adapter Valve | 1 | 10987 |
| 469 | Exhaust Cap | 1 | 21-1 |
| • 470 | Gasket | 1 | 94-029 |
| 473 | Crank Shaft Assembly | 1 | 94-001 |
| 474 | Connecting Rod Ring | 2 | 94-008 |
| 475 | Sleeve | 1 | 94-007 |
| 476 | Bushing | 1 | 94-006 |
| 478 | Setscrew | 1 | 94-005 |
| 479 | Pin | 1 | 94-004 |
| 480 | Capscrew | 1 | 51712 |
| 482 | Lockwasher | 1 | 50200 |

• Recommended spare.

* Motor Assembly includes items listed above.

FA2.5 MOTOR ASSEMBLY DRAWING



(Dwg. MHTPC0156)

FA2.5 MOTOR ASSEMBLY PARTS LIST

| ITEM NO. | DESCRIPTION OF PART | QUANTITY TOTAL | PART NUMBER |
|----------|----------------------------------|----------------|---------------------|
| - - - | Motor Assembly | 1 | K5B-546 |
| 3 | Lockwasher | 10 | 50201 |
| 4 | Capscrew | 10 | 14227 |
| 200 | Capscrew | 20 | 52317 |
| 201 | Cylinder Head | 5 | K5B-H505 |
| • 202 | Compression Ring | 5 | K5B-337-47 |
| 203 | Wrist Pin | 5 | HU-514A |
| 204 | Piston | 5 | Not Sold Separately |
| 205 | Retainer Ring | 10 | 902A45-632 |
| 206 | Connecting Rod | 5 | K5B-509 |
| • 207 | Oil Ring | 5 | K5B-338-47 |
| 208 | Cylinder Liner | 5 | K5B-L505-47 |
| • 209 | Head Gasket | 5 | K5B-507 |
| 201 | Vent Cap Assembly (Oil fill cap) | 2 | K5B-A303 |
| 211 | Baffle | 2 | K5B-528 |
| 212 | Screw | 4 | J-376 |
| 213 | Eye Bolt | 2 | KU-888 |
| 214 | Nameplate | 1 | K5B-301 |
| 215 | Drive Screw | 4 | R4K-302-12 |
| 216 | Mounting Flange | 1 | K5B-502 |
| 217 | Motor Housing | 1 | K5B-501 |
| 218 | Pipe Plug (Oil level) | 1 | ROH-377 |
| 219 | Pipe Plug | 1 | TC-368 |
| • 221 | Gasket | 1 | K5B-1002 |
| 222 | Cover Plate | 1 | K5B-1001 |
| 223 | Lockwasher | 6 | D02-321-10 |
| 224 | Capscrew | 2 | 119A2A202 |
| 225 | Pipe Plug (Drain) | 3 | GA57-95 |
| • 226 | Gasket | 1 | K5B-592 |
| • 227 | Oil Seal | 1 | K5B-270 |
| 228 | Crank Bearing * | 2 | Not sold separately |
| 229 | Button Head Screw * | 5 | Not sold separately |
| 230 | Oil Slinger * | 1 | Not sold separately |
| 231 | Crank Assembly | 1 | K5B-A516 |
| 232 | Sleeve * | 1 | Not sold separately |
| 233 | Connecting Rod Bushing * | 1 | Not sold separately |
| 234 | Connecting Rod Ring * | 1 | Not sold separately |

• Recommended spare.

FA2.5 MOTOR ASSEMBLY PARTS LIST

| ITEM NO. | DESCRIPTION OF PART | QUANTITY TOTAL | PART NUMBER |
|----------|----------------------|----------------|---------------------|
| 235 | Lock Pin * | 1 | Not sold separately |
| 236 | Cotter Pin * | 1 | Not sold separately |
| 237 | Pin Nut * | 1 | Not sold separately |
| 239 | Flat Head Screw | 1 | 139A2A266 |
| 240 | Roll Pin | 1 | WF171-15 |
| • 243 | Gasket | 2 | K5B-928 |
| • 244 | 'O' Ring | 1 | 20A11CM248 |
| 246 | Grease Fitting | 1 | 23-188 |
| 247 | Rotary Valve Housing | 1 | K5B-545 |
| • 248 | Gasket | 1 | K5B-547 |
| 250 | Rotary Valve | 1 | K5B-526 |
| • 251 | Seal Ring | 1 | K5B-607 |
| • 252 | Bearing | 1 | K5B-97 |
| 253 | Capscrew | 5 | 51471 |
| 254 | Exhaust Flange | 1 | K5B-276 |
| 255 | Capscrew | 2 | 119A2A200 |
| 256 | Lockwasher | 2 | D02-321-10 |
| 257 | Capscrew | 4 | 51766 |
| 260 | Valve Assembly | 1 | K5B-REMOTE |
| 317 | Gasket | 1 | K5B-275 |

• Recommended spare.


* Parts not sold separately. Refer to the "FA2.5 Motor Assembly Kit List."

** Motor Assembly consists of items 200 through 260 and 317.

FA2.5 Motor Assembly Kit List:

| ITEM NO. | DESCRIPTION OF PART | QUANTITY TOTAL | PART NUMBER |
|----------|--|----------------|-------------|
| 231 | Crank Assembly (Incl's items 206 and 228 through 237) | 1 | K5B-A516 |
| 261 | Piston Assembly (Incl's items 202 through 205 and item 207) | 1 | K5B-A513-47 |
| 262 | Cylinder Assembly (Incl's items 201 and 208) | 1 | K5B-A505-47 |

FA2 LIVE AIR CONTROL VALVE ASSEMBLY DRAWING AND PARTS LIST




(Dwg. MHTPA0203)

| ITEM NO. | DESCRIPTION OF PART | QTY TOTAL | PART NUMBER | ITEM NO. | DESCRIPTION OF PART | QTY TOTAL | PART NUMBER |
|----------|--|-----------|-------------|----------|---------------------|-----------|-------------|
| 260 | Valve Assembly (Incl's items 420 through 444) | 1 | 51710 | 431 | Capscrew | 2 | 51025 |
| 420 | Handle | 1 | 11882 | 432 | Sleeve | 2 | 71077473 |
| • 421 | Ball | 2 | 71077119 | 433 | Pipe Plug | 1 | 51599 |
| • 422 | Spring | 2 | 11862 | 434 | Pipe Plug | 1 | 11886 |
| 423 | Pin | 2 | 71077101 | 436 | Poppet Valve | 1 | 11879 |
| 424 | Washer | 2 | 52914 | 438 | Housing | 1 | * |
| 425 | Pin | 1 | 11860 | 439 | Grease Fitting | 1 | 50192 |
| 426 | Handle Bracket | 1 | 11878 | • 440 | Valve Bushing | 1 | 11883 |
| • 427 | Spring | 1 | 11880 | • 441 | Valve | 1 | 11865 |
| 428 | Pin | 2 | 52161 | 442 | Exhaust Cover | 1 | 11881 |
| 429 | Pin | 1 | 11861 | 443 | Lockwasher | 4 | 51801 |
| 430 | Screw | 2 | 11884 | 444 | Capscrew | 4 | 51770 |
| | | | | 444 | Capscrew | 4 | 51770 |

• Recommended spare.

* Not sold separately. Order Valve Assembly 51710 (item 260).

FA2.5 LIVE AIR CONTROL VALVE ASSEMBLY DRAWING AND PARTS LIST




(Dwg. MHTPA0165)

| ITEM NO. | DESCRIPTION OF PART | QTY TOTAL | PART NUMBER | ITEM NO. | DESCRIPTION OF PART | QTY TOTAL | PART NUMBER |
|----------|--|-----------|-------------|----------|--|-----------|-------------|
| 260 | Valve Assembly (Includes items 300 through 320) | 1 | K5B-REMOTE | 311 | Valve Housing (matched set with item 314) | 1 | K5B-1101 |
| 300 | Handle | 1 | K5B-556 | 312 | Roll Pin | 1 | 25A13C92 |
| 301 | Roll Pin | 1 | K5B-1115 | 313 | Grease Fitting | 1 | 23-188 |
| 302 | Capscrew | 2 | 50853 | 314 | Valve Bushing (matched set with item 311) | 1 | K5B-1101 |
| • 303 | Spring | 1 | K5B-412 | | | | |
| 304 | Lockwasher | 2 | 50200 | | | | |
| 305 | Valve Body Retainer | 1 | K5B-1110 | • 315 | Seal Ring | 2 | K5B-606 |
| | | | | 316 | Valve Body | 1 | K5B-944 |
| 306 | Spring Retainer | 1 | K5B-553 | 317 | Gasket | 1 | K5B-275 |
| 307 | Latch | 1 | K5B-869 | 318 | Flange | 1 | KK5B-276S |
| 308 | Roll Pin | 1 | HLK-20 | 319 | Lockwasher | 2 | D02-321-10 |
| 309 | Pipe Plug | 2 | E5UD-947 | 320 | Capscrew | 2 | 50853 |
| 310 | Pipe Plug | 1 | 71026025 | | | | |

• Recommended spare.

PILOT AIR CONTROL VALVE (OPTIONAL) ASSEMBLY DRAWING AND PARTS LIST




(Dwg. MHTPA0141)

| ITEM NO. | DESCRIPTION OF PART | QTY TOTAL | PART NUMBER | | |
|----------|--|-----------|-------------------------------------|------------|------------|
| | | | FA2 | FA2.5 | |
| | | | 310 size * | 410 size * | 510 size * |
| 355 | Valve Assembly (Incl's items 265 through 280) | 1 | 20991 | 20992 | 20993 |
| 265 | End Cap | 1 | 52241 | | 321-064 |
| • 266 | Gasket | 2 | 52457 | | 521-066 |
| 267 | Valve Body | 1 | Not sold separately, order item 355 | | |
| 268 | End Cap (Inlet Side) | 1 | 11778 | | |
| 269 | Capscrew | 8 | 52234 | | |
| 270 | Adjusting Screw | 1 | 71083968 | | |
| 271 | Nut | 1 | 52265 | | |
| 272 | Shoulder Screw | 1 | 817-002 | | |
| 273 | Guide | 1 | 52233 | | 321-071 |
| 274 | Spring | 1 | 52240 | | 814-019 |
| 275 | Washer | 1 | 52239 | | 321-072 |
| 276 | Spacer | 1 | 52238 | | 321-068 |
| • 277 | O' Ring | 6 | 51632 | | 808-013 |
| 278 | Valve Sleeve | 1 | Not sold separately, order item 355 | | |
| 279 | Valve Spool | 1 | Not sold separately, order item 355 | | |
| 280 | Stop | 1 | 11777 | | |

• Recommended spare.

* Consult the nearest Ingersoll-Rand office or distributor for technical assistance in determining the correct valve.

FA2 REMOTE AIR CONTROL (OPTIONAL) ASSEMBLY DRAWING AND PARTS LIST




(Dwg. MHTPA0204)

| ITEM NO. | DESCRIPTION OF PART | QUANTITY TOTAL | PART NUMBER |
|----------|------------------------|----------------|-------------|
| 408 | Control Valve Assembly | 1 | 51710 |
| 324 | Elbow Fitting | 1 | 52182 |
| 325 | Hose End | 2 | 51029 |
| 326 | Hose | 1 | 50923-* |
| 400 | Adapter Manifold | 2 | 17851 |
| 401 | Lockwasher | 8 | 50200 |
| 402 | Capscrew | 4 | 54240 |
| 403 | Elbow Fitting | 4 | 71015457 |
| 404 | Hose End | 4 | 54125 |
| 405 | Hose | 2 | 50766-* |
| 406 | Nut | 4 | 50170 |
| 407 | Capscrew | 4 | 51931 |

* Add hose length (feet/metres). Maximum length = 20 feet (6 metres). Contact Technical Sales for information on control applicability for lengths greater than 20 feet (6 metres).

FA2.5 REMOTE AIR CONTROL (OPTIONAL) ASSEMBLY DRAWING AND PARTS LIST




(Dwg. MHTPA0161)

| ITEM NO. | DESCRIPTION OF PART | QUANTITY TOTAL | PART NUMBER |
|----------|------------------------|----------------|-------------|
| 260 | Control Valve Assembly | 1 | K5B-REMOTE |
| 253 | Capscrew | 5 | 119A2A267 |
| 321 | Elbow Fitting | 4 | 54270 |
| 322 | Hose End | 4 | 54738 |
| 323 | Hose | 2 | 54737-* |
| 324 | Elbow Fitting | 1 | 52182 |
| 325 | Hose End | 2 | 51029 |
| 326 | Hose | 1 | 50923-* |
| 327 | Exhaust Cover | 1 | KK5B-276M |
| 329 | Lockwasher | 5 | 50181 |


* Add hose length (feet/metres). Maximum length = 20 feet (6 metres). Contact Technical Sales for information on control applicability for lengths greater than 20 feet (6 metres). Metres are for reference only; order quantities in feet.

REMOTE PILOT AIR CONTROL (OPTIONAL) ASSEMBLY DRAWINGS

**Valve Mount
FA2.5 Winch**



(Dwg. MHTPA0167)



**Valve Mount
FA2 Winch**

(Dwg. MHTPA0211)

REMOTE PILOT AIR CONTROL (OPTIONAL) ASSEMBLY PARTS LISTS

Remote Pilot Pendant Throttle Control

| ITEM NO. | DESCRIPTION OF PART | QTY TOTAL | PART NUMBER | | | |
|----------|------------------------|-----------|-------------|-------------|-------------|--------------|
| | | | 10 ft (3 m) | 20 ft (6 m) | 30 ft (9 m) | 40 ft (12 m) |
| 324 | Elbow Fitting | 4 | 52182 | | | |
| 325 | Hose End Fitting | See () | 51029 (6) | 51029 (10) | | 51029 (14) |
| 333 | Capscrew | 4 | 54681 | | | |
| 334 | Lockwasher | 4 | 50893 | | | |
| 335 | Manifold | 1 | 13881 | | | |
| 336 | Lockwasher (FA2) | 2 | 51486 | | | |
| | Lockwasher (FA2.5) | 4 | | | | |
| 337 | Capscrew | 4 | 50829 | | | |
| 338 | Nipple Fitting | 3 | 54274 | | | |
| 339 | Pipe Tee Fitting | 2 | 54678 | | | |
| 340 | Adapter Fitting | 2 | 51814 | | | |
| 341 | Hose Assembly | 1 | 17073-6 | | | |
| • 343 | Shuttle Valve | 1 | 50277 | | | |
| 344 | Hose Assembly (Brake) | 1 | 17073-10 | | | |
| 345 | Hose | See () | 50923-(132) | 50923-(242) | 50923-(233) | 50923-(245) |
| 346 | Adapter Fitting | As Req'd | --- | 71048284 | | |
| 347 | Exhaust Valve* | As Req'd | --- | 20417 | | |
| 348 | Adapter Fitting | As Req'd | 71048268 | | | |
| 349 | Hose | See () | --- | 50923-(6) | 50923-(123) | 50923-(6) |
| 350 | Hose | See () | 50923-(123) | 50923-(252) | 50923-(372) | 50923-(492) |
| 352 | Control Pendant | 1 | MLK-A269A | | | |
| 353 | Hose | See () | --- | 50923-(6) | 50923-(135) | 50923-(6) |
| 354 | Hose | See () | 50923-(120) | 50923-(230) | 50923-(233) | |
| 355 | Valve Assembly (FA2) | 1 | 20991 | | | |
| | Valve Assembly (FA2.5) | | 20992 | | | |
| 356 | Hose ** | See () | --- | --- | --- | 50923-(233) |
| 361 | Rotary Valve | 1 | 9148 | | | |
| 362 | Cover | 1 | 11543 | | | |
| 364 | Capscrew | 2 | 54840 | | | |
| 365 | Lockwasher | 4 | 51013 | | | |
| 366 | Capscrew | 4 | 52906 | | | |

• Recommended spare.

* Must be installed at 20 foot (6 metre) intervals. Part number 20417 includes items 346 and 348.

** Not shown. Install between exhaust valves. () = Quantity in inches.

Remote Pilot Lever Throttle Valve Associated Components

Note: Requires item #'s 325, 333 through 344 (Reference "Remote Pilot Pendant Throttle Control") plus the following parts.


| ITEM NO. | DESCRIPTION OF PART | QTY TOTAL | PART NUMBER | ITEM NO. | DESCRIPTION OF PART | QTY TOTAL | PART NUMBER |
|----------|---------------------|-----------|-------------|----------|----------------------|-----------|-------------|
| 345 | Hose | See () | 50923-(233) | 350 | Hose | See () | 50923-(372) |
| 346 | Adapter Fitting | 2 | 71048284 | 353 | Hose | See () | 50923-(123) |
| 347 | Exhaust Valve ** | 2 | 71047898 | 354 | Hose | See () | 50923-(233) |
| 348 | Adapter Fitting | 1 | 71048268 | 357 | Elbow Fitting | 2 | 51281 |
| 349 | Hose | See () | 50923-(135) | 358 | Pilot Lever Throttle | 1 | 71069561 |

* Part numbers and quantities are for a 30 foot (9 metre) hose assembly.


() = Quantity in inches.

MUFFLER ASSEMBLY DRAWINGS


FA2.5 Muffler with Remote Actuated Pilot Control Valve (Old Style)




FA2.5 Mufflers with Remote Actuated Pilot Control Valve (New Style)



FA2.5 Muffler with Live Air Throttle Valve



FA2 Mufflers with Remote Actuated Pilot Control Valve



(Dwg MHTPA0515)

MUFFLER ASSEMBLY PARTS LIST

| ITEM NUMBER | DESCRIPTION OF PART | QUANTITY TOTAL | PART NUMBER |
|----------------|------------------------|-------------------|-------------|
|----------------|------------------------|-------------------|-------------|

FA2 with Live Air Throttle Valve

| | | | |
|-----|-------------|---|-------|
| 169 | Pipe Elbow | 1 | 52103 |
| 170 | Muffler | 1 | 52465 |
| 171 | Pipe Nipple | 1 | 51704 |

FA2 with Remote Actuated Pilot Valve

| | | | Old Style | New Style |
|-----|-------------|---|-----------|-----------|
| 169 | Pipe Elbow | 1 | 53368 | 52103 |
| 170 | Muffler | 1 | 50592 | 52465 |
| 171 | Pipe Nipple | 1 | --- | 51704 |
| 172 | Pipe Elbow | 1 | 52190 | 53368 |
| 173 | Muffler | 1 | 52104 | 50592 |

FA2.5 with Live Air Throttle Valve


| | | | |
|-----|-----------------|---|----------|
| 165 | Reducer Bushing | 1 | 71057459 |
| 167 | Pipe Nipple | 1 | 71057467 |
| 169 | Pipe Elbow | 1 | 71057434 |
| 170 | Muffler | 1 | 50594 |

FA2.5 with Remote Actuated Pilot Valve

| | | | Old Style | New Style |
|-----|-----------------|---|-----------|-----------|
| 160 | Pipe Nipple | 1 | 71057491 | --- |
| 161 | Pipe Elbow | 1 | 71033450 | --- |
| 162 | Hose Clamp | 2 | 71033500 | --- |
| 163 | Pipe Nipple | 2 | 71057483 | --- |
| 164 | Hose | 1 | 71033492 | --- |
| 165 | Reducer Bushing | 1 | 71057459 | --- |
| 166 | Pipe Tee | 1 | 71057442 | --- |
| 167 | Pipe Nipple | 1 | 71057467 | |
| 168 | Pipe Nipple | 1 | 71057475 | --- |
| 169 | Pipe Elbow | 1 | 71057434 | |
| 170 | Muffler | 1 | 50594 | |
| 171 | Pipe Nipple | 1 | --- | 51704 |
| 172 | Pipe Elbow | 1 | --- | 52103 |
| 173 | Muffler | 1 | --- | 52465 |

Note: Reference the "PILOT AIR CONTROL VALVE ASSEMBLY DRAWING AND PARTS LIST" section for Pilot Valve Assembly (355) component part numbers

PENDANT CONTROL ASSEMBLY (OPTIONAL) DRAWING AND PARTS LIST



(Dwg. MHTPA0168)


| ITEM NO. | DESCRIPTION OF PART | QTY TOTAL | PART NUMBER |
|----------|---------------------|-----------|-------------|
| 352 | Pendant Assembly * | 1 | MLK-A269A |
| 370 | Pendant Handle | 1 | MLK-269 |
| 371 | Throttle Valve | 2 | MLK-K264A |
| 372 | Throttle Valve Face | 2 | R000BR1C-2 |
| • 373 | Spring | 2 | MKL-51A |
| 374 | Throttle Valve Cap | 2 | MLK-266A |
| • 375 | Valve Cap Gasket | 2 | MLK-504 |

| ITEM NO. | DESCRIPTION OF PART | QTY TOTAL | PART NUMBER |
|----------|---------------------|-----------|-------------|
| 376 | Lever | 2 | MLK-273 |
| 377 | Throttle Lever Pin | 1 | DLC-120A |
| 378 | Pin Lock Washer | 2 | D02-138 |
| 379 | Support | 1 | MLK-450 |
| 380 | Lockwasher | 2 | H54U-352 |
| 381 | Handle Screw | 4 | HRE20A-68 |
| 382 | Hose Fitting | 3 | 52092 |

• Recommended spare.

* Assembly includes items 370 thru 381.

DRUM LOCKING PIN (OPTIONAL) ASSEMBLY DRAWING AND PARTS LIST




(Dwg. MHTPB0155)

| ITEM NO. | DESCRIPTION OF PART | QUANTITY TOTAL | PART NUMBER |
|----------|---------------------------|----------------|-------------|
| 80 | Drum (without band brake) | 1 | 16330* |
| | Drum (with band brake) | | 16331* |
| 84 | Outboard Upright | 1 | 16327 |
| 135 | Pin | 2 | 51933 |
| 136 | Lock Pin | 1 | 16328 |
| 137 | Spring | 1 | 54453 |
| 138 | Gland | 1 | 16329 |
| 139 | Grease Fitting | 1 | 53498 |
| 140 | Pull Rod | 1 | 16310 |

* Part numbers reference the drawings required for information on drilling holes in the drum flange for locking pin installation. Contact Ingersoll-Rand Technical Sales or the factory for assistance.

DRUM GUARD ASSEMBLY DRAWING AND PARTS LIST




(Dwg. MHTPA0205)

| ITEM NO. | DESCRIPTION OF PART | QUANTITY TOTAL | PART NUMBER |
|----------|---|----------------|-------------|
| * | Drum Guard Assembly (8 inch long drum) | 1 | 11283-1 |
| | Drum Guard Assembly (12 inch long drum) | | 11283-2 |
| | Drum Guard Assembly (16 inch long drum) | | 11283-3 |
| | Drum Guard Assembly (24 inch long drum) | | 11283-5 |
| 150 | Capscrew | 4 | 71072243 |
| 151 | Clamp | 4 | 10399 |
| 152 | Support | 2 | 10400 |
| 153 | Drum Guard (8 inch long drum) | 1 | 11259-1 |
| | Drum Guard (12 inch long drum) | | 11259-2 |
| | Drum Guard (16 inch long drum) | | 11259-3 |
| | Drum Guard (24 inch long drum) | | 11259-5 |
| 154 | Lockwasher | 4 | 51580 |
| 155 | Nut | 4 | 71061584 |
| 156 | Capscrew | 4 | 53391 |
| 157 | Washer | 4 | 50182 |

* Drum Guard Assemblies include items 150 through 157.

AIR PREPARATION ASSEMBLY DRAWING AND PARTS LIST



(Dwg. MHTPA0223)

| ITEM NO. | DESCRIPTION OF PART | QTY TOTAL | PART NUMBER |
|----------|--------------------------|-----------|-------------|
| * | Air Preparation Assembly | 1 | 10389 |
| 575 | Filter | 1 | F42-0A-000 |
| 576 | Pipe Nipple | 2 | 51670 |
| 577 | Regulator | 1 | R30-0A-G00 |
| 578 | Pipe Nipple | 1 | 51704 |
| 579 | Pipe Bushing | 2 | 51706 |
| 580 | Lubricator | 1 | L40-0A-G00 |
| 582 | Relief Valve | 1 | 51702 |
| 583 | Pipe Nipple | 1 | 50933 |

| ITEM NO. | DESCRIPTION OF PART | QTY TOTAL | PART NUMBER |
|----------|---------------------|-----------|-------------|
| 584 | Pipe Bushing | 1 | 51705 |
| 585 | Pipe Tee | 1 | 51707 |
| 586 | Regulator | 1 | 51802 |
| 587 | Pipe Nipple | 1 | 51804 |
| 588 | Pipe Bushing | 1 | 51803 |
| 589 | Pipe Elbow | 4 | 51805 |
| 590 | Hose End | 4 | 51806 |
| 591 | Hose | () | 51807-(8) |
| 592 | Hose | () | 51807-(11) |

* Air Preparation Assembly for 1-1/4 inch system.

() = Quantity in inches.

PARTS ORDERING INFORMATION

Use of other than **Ingersoll Rand** replacement parts may adversely affect the safe operation and performance of this product.

For your convenience and future reference it is recommended that the following information be recorded.

Model Number _____

Serial Number _____

Date Purchased _____

When ordering replacement parts, please specify the following:

1. Complete model number and serial number as it appears on the nameplate.
2. Part number(s) and part description as shown in this manual.
3. Quantity required.

The nameplate is located on the winch outboard upright.

NOTICE

- Continuing improvement and advancement of design may cause changes to this equipment which are not included in this manual. Manuals are periodically revised to incorporate changes. Always check the manual edition number on the front cover for the latest issue.
- Sections of this manual may not apply to your winch.
- The use of other than genuine Ingersoll Rand replacement parts may result in safety hazards, decreased performance and increased maintenance and invalidate all warranties.

Return Goods Policy

Ingersoll Rand will not accept any returned goods for warranty or service work unless prior arrangements have been made and written authorization has been provided from the location where the goods were purchased.

Winches which have been modified without **Ingersoll Rand** approval, mishandled or overloaded will not be repaired or replaced under warranty. A printed copy of the warranty which applies to this winch is provided inside the back cover of this manual.

Disposal

When the life of the unit has expired, it is recommended that it be disassembled, degreased and parts separated as to materials so that they may be recycled.

For additional information contact:

Ingersoll Rand

2724 Sixth Avenue South
Seattle, WA 98134 USA
Phone: (206) 624-0466
Fax: (206) 624-6265

or

Ingersoll Rand

Douai Operations
529, Avenue Roger Salengro
59450 Sin Le Noble, France
Phone: (33) 3-27-93-08-08
Fax: (33) 3-27-93-08-00

WARRANTY

LIMITED WARRANTY

Ingersoll Rand Company (I-R) warrants to the original user its Hoists and Winches (Products) to be free of defects in material and workmanship for a period of one year from the date of purchase. **I-R** will repair, without cost, any Product found to be defective, including parts and labor charges, or at its option, will replace such Products or refund the purchase price less a reasonable allowance for depreciation, in exchange for the Product. Repairs or replacements are warranted for the remainder of the original warranty period.

If any Product proves defective within its original one year warranty period, it should be returned to any Authorized Hoist and Winch Service Distributor, transportation prepaid with proof of purchase or warranty card.

This warranty does not apply to Products which **I-R** has determined to have been misused or abused, improperly maintained by the user, or where the malfunction or defect can be attributed to the use of non-genuine **I-R** parts.

I-R makes no other warranty, and all implied warranties including any warranty of merchantability or fitness for a particular purpose are limited to the duration of the expressed warranty period as set forth above. I-R's maximum liability is limited to the purchase price of the Product and in no event shall I-R be liable for any consequential, indirect, incidental, or special damages of any nature rising from the sale or use of the Product, whether based on contract, tort, or otherwise.

Note: Some states do not allow limitations on incidental or consequential damages or how long an implied warranty lasts so that the above limitations may not apply to you.

This warranty gives you specific legal rights and you may also have other rights which may vary from state to state.

IMPORTANT NOTICE

It is our policy to promote safe delivery of all orders.

This shipment has been thoroughly checked, packed and inspected before leaving our plant and receipt for it in good condition has been received from the carrier. Any loss or damage which occurs to this shipment while enroute is not due to any action or conduct of the manufacturer.

Visible Loss or Damage

If any of the goods called for on the bill of lading or express receipt are damaged or the quantity is short, do not accept them until the freight or express agent makes an appropriate notation on your freight bill or express receipt.

Concealed Loss or Damage

When a shipment has been delivered to you in apparent good condition, but upon opening the crate or container, loss or damage has taken place while in transit, notify the carrier's agent immediately.

Damage Claims

You must file claims for damage with the carrier. It is the transportation company's responsibility to reimburse you for repair or replacement of goods damaged in shipment. Claims for loss or damage in shipment must not be deducted from the **Ingersoll Rand** invoice, nor should payment of **Ingersoll Rand** invoice be withheld awaiting adjustment of such claims as the carrier guarantees safe delivery.

You may return products damaged in shipment to us for repair, which services will be for your account and form your basis for claim against the carrier.

