



## OPERATION MANUAL

📞 (800) 878-7305 📧 Rentals@RentLGH.com 🌐 RentLGH.com



# 2020SC Operational Manual

1505 7<sup>th</sup> ST  
E. Moline, IL 61244  
Phone (309) 764-9842  
Fax (309) 764-9848  
Email: [liftit@lift-systems.com](mailto:liftit@lift-systems.com)  
Web: [www.lift-systems.com](http://www.lift-systems.com)

## 2020SC TABLE OF CONTENTS

<b>Model Specifications</b>			
Specifications	A-1	Load charts	E-14
Handling of lift units	A-2	Beams	E-15
<b>Introduction</b>			
Introduction	B-1	Header plates	E-15
Design	B-1	Directional valves	E-15
Operating Characteristics	B-2	Optional wireless radio	E-16
Capacities & Stabilization	B-2	Utilization Chart	E-18
Warning & Cautions	B-2	<b>Maintenance</b>	
Maintenance records and Logs	B-2	Hydraulic oil	F-1
Warning signs	B-3	Wheel lubrication	F-1
Decals	B-4	Oil maintenance	F-2
<b>Do's Don'ts and Warnings</b>		Oil level & temperature	F-2
Always do the following	C-1	Suction strainer	F-2
Never do the following	C-2	Hydraulic filter	F-3
Warnings	C-3	Operating temperatures	F-3
<b>Preparation and Setup</b>		System maintenance	F-3
Pre-start inspection	D-1	Bolt torque chart	F-4
Pre-operational checklist	D-1	Cylinder packing replacement	F-5
Annual inspection	D-2	Bleeding procedure	F-5
Overall Cleanliness	D-3	Adding pin on drives	F-6
Hydraulics	D-3	Maintenance chart	F-9
Lubrication	D-3	Troubleshooting	F-10
Structural	D-3	Testing a cylinder for bypass	F-13
Maintenance records	D-3	Steel wheel and bearing replacement	F-15
Equipment Utilization records	D-3	Cylinder removal	F-19
Preparation and Setup	D-4	Replacing counter balance valve	F-23
Lay out the lift	D-8	Chain tensioning and motor replacement	F-28
<b>Operation</b>		Replacing bearings on integral drives	F-31
Connecting and basic operation	E-1	Replacing pump	F-34
Pressure gauges	E-2	Replacing the filter	F-36
Travel	E-2	Suction strainer	F-37
Sight gauge	E-3	Operating pressure	F-39
Hydraulic filter dirt indicator	E-3	Replacing cylinder rod seals	F-40
Operating temperatures	E-4	Complete cylinder reseal	F-46
Lifting a load	E-4	<b>Options</b>	
Traveling	E-7	Level-Lift systems	G-1
Controlling speed when loaded	E-9	Propels	G-1
Using load chart	E-10	Side Shifts	G-3
Load chart checklist	E-13	<b>Parts</b>	
			H1

## MODEL SPECIFICATIONS

- Weight of each lifting unit; 1900lbs
- Lifting unit dimensions; 72"H 28" W 51" L
- Capacity of power units in gallons; 19 gallons
- Maximum capacity of 2-point system: 20 tons.
- Maximum capacity of each leg: 10 tons.
- Retracted height: 72"
- Maximum extended height: 16'
- Maximum operating pressure: 1800psi

## POWER OPTIONS


### ELECTRIC OPTION

1-1/2HP, 1800RPM @ 115/208-230VAC, 1.12KW, FLA 15.2/8.2-706 @ 60 Hz single phase.

1HP. 1500RPM @ 110/220VAC, .75KW, FLA 15.6/7.8 @ 50 Hz single phase.

### FRAME SIZE 56HC

The maneuvering dolly allows the lifting units to be positioned accurately during setup. Never attempt to reposition or steer a lifting unit while loaded. To use the dolly, insert the pin on the dolly into the bracket that is located on the one end of the base. Push down on the handle of the dolly which will lift that end of the base to where the wheels are off the ground. The base can be pushed or pulled into position. To steer simply pull the dolly to the left or right.



## INTRODUCTION

### Introduction

The lift system consists of two or more bases. Standard equipment consists of:

- Maneuvering Dolly
- Self-contained power unit
- Double-acting telescopic cylinder
- High capacity, low friction wheels
- Lifting beam attachment assembly
- Remote Control

Some units may have optional equipment such as:

- Power drive
- Hard poly type tires
- European style power system

This manual will concentrate on standard equipment usage and safety procedures. Optional equipment is discussed in separate inserts to this manual.

### Design

This lift system is designed for accurate precise lifting and smooth movement of loads specified by the load chart. It is designed to be very stable when used in accordance with good and safe rigging practices by competent rigging and maintenance personnel. All procedures set forth in this manual are based on the safe operation of this lift system under proper operating conditions and without deviations from the system as it was originally intended to be used.

All Lift Systems equipment is designed and tested to the following codes and standards.

- AISC Allowable Stress Design 14<sup>th</sup> Edition.
- AWWs D1.12010, Structural Steel Welding.
- Certified Material Mill Reports traceable to the appropriate heat numbers for all affected parts are mandatory and retained in serial numbered machine files.
- LPI and MPI I accordance with ASNT, level 2 including NDE qualified personnel.
- Specification for structural joints using ASTM A325 or A490 bolts, ASIC.
- Raw material designation in accordance with ASTM or AISI standards.
- Slings in accordance with ASME B30.9
- Hydraulic Gantry Systems in accordance with ASMEb30.1-2015 telescopic hydraulic Gantry Systems.
- Mobile Pick and Carry machines in accordance with ASME B56.7 Industrial Hoist trucks.
- Lift Units in accordance with SAEJ1078 – a recommended method of analytically determining the competence of hydraulic telescopic cantilevered booms.
- Model testing accordance with current ASME and CE standards.

There are several warning signs on the system, which fall into four categories. The labels are harmonized to meet both ANSI and the EU Machinery Directive:



- **DANGER:** Notifies the operator when there is a hazardous situation, which has a **high** probability of death or severe injury.



- **WARNING:** Notifies the operator when there is a hazardous situation, which has **some** probability of death or severe injury.



- **CAUTION:** Notifies the operator when there is a hazardous situation, which may result in minor or moderate injury.



- **MANDATORY ACTION:** This label tells you about an action that **NEEDS** to be taken to avoid the hazard (e.g. "read manual").



- **WARNING SIGN:** This label is meant to tell you what the hazard is (e.g. "fire hazard").



- **PROHIBITION SIGN:** This label tells you about an action **NOT** to take to avoid a hazard (e.g. "no open flame").



- **CAUTION:** Without the safety, alert symbol tells you about potential "property damage only."

Make sure that you can read all warning and instruction labels. If you cannot read the words or see the pictures, clean the label with soap, water, and a cloth. If the label is damaged, missing or cannot be read, you must replace the label. Contact Lift


## DO'S, DON'TS AND WARNINGS

### ALWAYS DO THE FOLLOWING

- Understand all system operations, including the safety procedures, before accepting any operating or maintenance responsibility.
- Perform complete pre-start inspection of the system before each use. Perform required maintenance functions before beginning lifting or traveling.
- Be alert to any space problems and clearances required, including overhead cranes in the area, before starting any system movement. Plan your lift in advance.
- Check to make sure all lifting units are level and plumb at all points. Check often during lifting and traveling to make sure that the system remains level and plumb. Use accurate levels to determine whether the system is level and plumb.
- Check all rigging (shackles, chokers, etc.) to verify capability of handling specified load. It is the customers responsibility to ensure all rigging attachments are rated for the lift.
- Have all lifting beams and runway track approved by a qualified professional engineer before the lift. Check for structural verification of the capacities based upon lifting points and load distribution. Check for stress level and deflection in both.
- Use runway track. Shim the runway track every three feet. Have a qualified professional engineer verify capacity to span lengths greater than three feet, or when the system will be traveling over pits or open areas in the floor.



- Allow people to do any work under a suspended load unless safety cribs or stands are installed to support the load during the process.



- Allow anyone to override or bypass safety devices.
- Allow anyone to change or alter the plumbing, electrical, or fabricated assemblies without the expressed permission of the manufacturer.
- Underestimate the power of this system.
- Never allow anyone to stand on a unit when lifting, lowering or traveling.

**WARNING!**

**Do not adjust any factory-preset valves without the express permission and written technical instructions from the manufacturer.**

**WARNING!**

**Do Not attempt to adjust any part of the wedge system or the proximity switches without express permission and written technical instructions from the manufacturer. Improperly adjusted wedges and proximity switches could result in damage to the system.**

**WARNING!**

**Do Not Weld on any part of the system. Never attach a welding ground to the lifting units. Doing so could cause an electrical arc between the cylinder pistons and the bores of the cylinders. This can cause damage that could score the bores causing internal bypass and the cylinder will no longer be able to hold a load until it is repaired.**

**WARNING!**

Always keep feet clear of wheels when traveling.

**WARNING!**

Before lifting or traveling make sure all the selector valves are in the same position. Having one in lift and one in propel can be extremely dangerous. The system can quickly become unstable which can cause damage, injury or even death.

**WARNING!**

Never attempt to lift a load during strong winds or gusts. It is possible for the load to swing or the entire system to move down the track in strong winds.

**WARNING!**

Never attempt to make a lift during a storm or when lighting may occur.

**WARNING!**

Never use power cords that are too small or too long. Doing so can cause the circuit breakers to trip, motors to overheat and cause the motor starters to overheat and fail. Cords should be at 12 gauge or larger with the length at a minimum. If a power outlet is too far away consider using a portable generator.

## Preparation and Setup

### Pre-start Inspection

It is the user's responsibility to inspect the lift system before operation begins. It is recommended that inspection of the system take place though other personnel recently operated the lift system.

The walk-around inspection, or visual inspection, is the most efficient method of checking your system. The purpose of the inspection is to insure that the system is in good operating order before it is used.

### Pre-operational Checklist

Before making, every lift an inspection should be made of the system. Below is a checklist of items to inspect.

- If gas or diesel powered, check the engine oil levels.
- If water-cooled, check the water level.
- Check fuel level.
- If electric option check to see if there sufficient power at job site to operate the system.
- Check for strange noises coming from electric motor when running.
- Check power cords for the proper gauge. Use 12gauge or larger, 10 gauge is the preferred size.
- Check power cords for damage.
- Check hydraulic oil level. (The lift cylinders must be fully retracted.)
- Check oil for cloudy or milky appearance. (This means there could be water in the oil, which causes loss of lubrication and component failure.)
- Check for leakage around tops of cylinders. (A little dampness over time is normal; oil running down the cylinder is not, new rod seals maybe required.)
- Check hose reel hoses for damage. (A damaged hose could burst under pressure.)

---

customer's facility with a company representative present. If the customer wishes to perform the test at their site, the customer must have known test weights that are certified.

### **Overall Cleanliness**

Check all system surfaces to be sure they are cleared of any oil, or foreign objects (rags, papers, tools, etc.).

### **Hydraulics**

Check for fluid leaks or any signs of physical damage or wear in the hydraulic system.

### **Lubrication**

Check the maintenance record to see if lubrication is necessary before operation. A lubrication chart is provided with details on specifications.

Check the oil level in the hydraulic reservoir. With the cylinder fully retracted, it should be at the top of the sight gauge. One inch of air space is required above the sight gauge level for oil expansion.

### **Structural**

Check the entire unit for any signs of physical damage. Look for any signs of failure. Consult the factory if any damage or failure has occurred.

### **Maintenance Records**


Update your maintenance records each time the system is serviced. The lift of this system will depend upon its proper care and maintenance.

### **Equipment Utilization Records**

Authorized users should document usage of the system to assist other personnel in operating and maintaining this system properly.

**Warning!**

Make absolutely sure the track sections are bolted to each other end to end and never use the track without the cross members. Failure to do so could cause the track to slip out from under the lifting units causing serious damage to the load or equipment and, injury or death to personnel.

**Warning!**


Track must be kept level; otherwise, the system will become side-loaded and unstable.

**WARNING!**

If setting the track up on frozen ground even with crane mats use extreme caution. In the right conditions such as when the ambient temperature raises to near above freezing the weight of the load can force the frost out of the ground causing the ground to shift or to settle which will cause the system to go rapidly out of level.

**WARNING!**

If setting the track up inside a building where there may be a basement or some sort of a void be sure to consult with an engineer to determine if the flooring can adequately support the weight of the system and the load.




4. The lifting points on the beam, where lifting links are placed should be kept as close to the lifting units as possible to minimize deflection.


5. The lifting beam span should be as short as possible to minimize deflection.

6. The load on each lifting unit should be as equal as possible to minimize the chance of overload.

In addition to these steps, it is recommended that the practices in the published by "Recommended Practices for Telescopic Hydraulic Gantry Systems" manual, by the S.C.R.A. are followed. This manual maybe purchased through the S.C.R.A. website <http://www.scranet.org/store/>.



7. Place beams onto header plates and install safety beam clips. If lifting links are to be used, place links onto the beams before setting them in place and position according to placement of lifting devices or chokers necessary to lift the load.



8. Attach the load with rigging equipment rated for the full capacity of the lift unit. Rigging equipment should have appropriate safety factors.

9. Upon starting the system, allow it to idle for a few minutes and listen for any unusual noises.

10. If the system is equipped with a drive option, make sure the drives are freewheeling before the lift is attempted.

**Caution!**


If any unusual noises are heard, shut the system down and refer to the troubleshooting section of this manual for possible problems and resolutions.

## Operation

### Connecting and basic operation


To operate the 2020SC two 20amp (110VAC) circuits will be required, (220VAC is available) if both bases are plugged into the same circuit. The circuit breaker will trip when the motors begin to see a load either when lifting a load or during lowering of the system. In addition, using a too long of a power cord or to small of gauge of wire can cause the breakers to trip. Whenever there is a problem with the motors stalling or the breakers tripping first try replacing the cords with a shorter cord, heavier gauge cord or both. 10 gauge is the preferred size.

Before connecting the power cords, first connect the pendent control, the connectors on the pendent should be label 1 and 2. Make sure they correspond with the bases. The "ON/OFF" switch is in the "OFF" position and the E-Stop on the pendent is depressed. Connect the power cords, pull the E-Stop and turn the "ON/OFF" switches to "ON". Do not use the E-Stop to turn the system on and off.



**Hydraulic Oil Sight Level Gauge and Thermometer:**

The sight level gauge is useful in determining the amount of oil in the power unit reservoir. The gauge is typically mounted on the long inside surface of the oil reservoir at the top. This gauge will indicate full when all cylinders in the lifting units are fully retracted. Do not overfill the reservoir. Leave 1 to 2 inches of air space for oil expansion when hot. The gauge also shows the temperature of the hydraulic oil. If there is no sign of oil in the sight gauge with all the cylinders fully retracted, oil must be added before using the system.

**Hydraulic Oil Filter Dirt Indicator:**

Each unit is equipped with a return filter that is mounted in the top of the reservoir. On each filter there is a dirty filter indicator. Some indicators are color coded, if the needle get into the red area the filter element must be replaced. Other indicators just have numbers; if the needle goes beyond 20 then the element needs to be replaced.





If equipped with the pin on ratchet type drives use the ratchet to lift the drive wheel up so that is not making contact. This will ensure the system will in free wheel when beginning the lift.

Check the load chart again to determine the amount of hydraulic pressure to lift the load. Do not lift the load completely without knowing the pressure required.

Jog the control switches to slowly apply pressure in the Cylinder until the pressure gauge reaches the pressure reading you have gotten from the load chart. Applying pressure rapidly may cause a false pressure reading.


### **Warning!**

**If the pressure specified on the load chart is reached and the load is not lifting.**

- A. The load could be heavier than calculated.
- B. The load is tied or fastened down.
- C. The lifting units are not level and plumb, causing side loads on the cylinders and more pressure needed to overcome the friction caused by side load.
- D. Faulty gauges.
- E. Excessive beam deflection, causing a cylinder side load

### **Stop!**

Check the lifting units for level and plumb, the beam and track (as required) for deflection. If the lift set-up is proper, the load may be heavier than calculated. If you continue to increase the pressure, you may overload the rigging equipment (chokers and shackles). Make sure the rigging can take the increased load before going to higher pressures.

**Warning!**

Do not come into the load suddenly if the cylinders are in a miss-stage condition. Gently ease into the load so the cylinders can restage using the load to induce the right sequence hydraulically. If the sections do not extend and/or retract in proper sequence with a load, consult the manufacturer immediately.

**Warning!**

Always make sure the ends of the header beam extend out over the edge of the header plates. If they are not there is the chance the lifting unit could be forced out from under the beam if it were to become unleveled.

**Traveling**

The system lifting units must always be level and plumb during lifting and traveling with loads. When traveling with loads, track should be level and parallel to line of travel. Shim all low areas to ensure that the system units remain level and plumb during travel. Avoid sudden stops and starts that could cause the load to swing. Always make sure the cords stay clear of the wheels when traveling. There is an adjustable needle valve for controlling the travel speed.

**Caution!**

The lifting units should always operate parallel to each other. Incorrect relationship between system units, such as allowing one side to get ahead of the other while traveling, will create side loads in extended cylinders creating rapid packing wear and possible damage to the cylinder rods. See following drawing on the next page.

**Warning!**

The foundation supporting the track (as required) and the lifting units must be firm enough to support the combined weight of the load, lifting units, beam and track without settling or sinking. Any change in the support area under the track or lifting units during the lift or while traveling is very dangerous and must always be monitored by the personnel operating the system.

**Warning!**

The weight of the load adds to the speed when retracting the cylinders. Be careful!! It may be necessary to jog the control switches to slowly lower the load. Alternatively, the flow control can be adjusted to slow the speed of the system when in a load condition. See the next page for more information.

**Controlling the speed when loaded**

The 2020SC system is equipped with flow control valves. Each lifting unit has its own flow control so they can be adjusted accordingly to the load it is carrying. The heavier the load the faster the system will lower. To use the flow controls, turn the knob clockwise to slow the cylinder down, and counterclockwise to speed the cylinder up. Each flow control has colored rings to help take the guesswork out of where to adjust them. You can never be too slow when lowering a load, so it is better to start out setting them slow. However, use caution when adjusting; even with the colored rings it is still possible to have one adjusted faster or slower than the other. In addition, it also depends how the load is centered with the system. If one cylinder is carrying more of the load than the other cylinder, then that cylinder will want to lower faster. It is advisable once the controls are adjusted to lower the system slightly to determine if one needs to be slowed down some more. These are not intended to keep the system level, only to control the speed. It is still the operators' responsibility to make sure the system stays level and plumb.

Flow control valve can be used to control lowering speed when in a loaded condition.



---

**How to Use the Control Valve and Pressure Gauges to Verify the Load Using the Load Chart Check List on page E-13.**

Before the lift, fill out the load chart checklist with the pressure required at each lifting unit.

**"Lift Load" Pressure:**

First, use the load chart provided to determine the amount of pressure needed to lift the required load. Make sure the additional weight of any rigging or lifting beams used are included in the calculation of total load. Next, fill in the pressure required for each lifting unit in the "lift load" line on the form. Then, the operator will know when the lifting unit(s) reaches the pressure reading, which should be moving the load.

**"Stop Limit" Pressure:**

Determine the smallest amount of safety factor available in lifting beams, track, and rigging in case of overload. Convert this to a load figure. This figure should be equal to, or greater than, the load you have calculated above. Use the load chart again to fill in "stop limit" pressure. The range of pressure between "lift load" and "stop load" must not be more than 200 PSI. In the case of a maximum load for that stage, the pressure to lift or stop will be the same.

Before starting the lift, all propel, or drive options should be unpinned or shifted to freewheel. When beginning a lift, pull the valve handles gradually to insure accurate readings on pressure gauges. As pressure increases to the predetermined lift pressure, watch for the load to begin moving. If the load begins moving before the pressure is reached, the load weighs less than calculated. Depending upon the weight of the load, further movement of the handles may result in faster movement of the load. A higher-pressure reading may occur due to increased resistance with increased flow and natural frictional losses in hoses, couplers, and valves.

**Caution!**

**When the load starts to clear its supporting foundation, it may want to sway a little so it can find its center with the lifting system. The lifting process should be stopped until the load has stopped swaying.**

If the load has not moved when the "stop limit" pressure is reached the operator should stop. If you continue to lift, you may overload and break chokers and shackles, or cause deflection in lifting beams, runway track, or the foundation support under the lifting units. Identify the problem and take whatever steps are required to solve it, and then proceed with the lift.

## LOAD CHART CHECKLIST

LIFTING UNIT #1			LIFTING UNIT #2		
Approximate lifting weight _____			Approximate lifting weight _____		
<b>Approximate pressure</b>			<b>Approximate pressure</b>		
Stage	Lift load	Stop Limit	Stage	Lift load	Stop Limit
#1	PSI	PSI	#1	PSI	PSI
#2	PSI	PSI	#2	PSI	PSI
#3	PSI	PSI	#3	PSI	PSI

LIFTING UNIT #3			LIFTING UNIT #4		
Approximate lifting weight _____			Approximate lifting weight _____		
<b>Approximate pressure</b>			<b>Approximate pressure</b>		
Stage	Lift load	Stop Limit	Stage	Lift load	Stop Limit
#1	PSI	PSI	#1	PSI	PSI
#2	PSI	PSI	#2	PSI	PSI
#3	PSI	PSI	#3	PSI	PSI

**CAUTION!**

The load charts are with all the cylinders equally loaded. If the total weight of the load is well within the lift limits of the system it is still possible to overload at least one cylinder, depending on how the weight is distributed on each cylinder.

**NOTE**

The pressures shown on the load charts are how much pressure it takes to support the load. The actual pressure required to move the load will be higher.

If the gauges read a higher pressure than expected, make another walk-around inspection to make sure that the beam deflection is not excessive. This condition must always be avoided.

Be certain that the load is not tied down. Verify, if possible, the weight of the load, beam, and rigging.

### Beams

Always be certain that beams used are of proper strength to carry the load to be lifted and that the spacing of the lifting links, or other load attachments, is sufficient to ensure proper and safe loadings within the capacity of the beams.


A qualified, professional engineer should verify all lifting beam load capacities before making a lift. There is a lift beam program available at <http://www.liftbeam.com> you can use. You must sign up and there are fees required to use the application. In addition, when going to the lift beam site, there you will find a chart for hydraulic gantry hand signals.

### Header Plates


The centerline of the lifting beam must be kept directly over the centerline of cylinders. If using a narrower beam than that for the header plates are designed, use spacers on both sides of the beam to keep it centered on the header plates. Header plates are designed to pivot which helps keep the load on the center line of the lifting unit when the beam come slightly out of level.

### Directional Valves for Lift/Lower & Propel

Electric shift valves for lift and lower or for propel option are mounted on a pedestal on top of the hydraulic reservoir. Propel may be controlled by a manual valve mounted on pedestal on the base top plate. These valves must not be used for a step. Electric shift valves are spring loaded to the neutral position in case of power or valve failure. If a lifting unit malfunctions, check these valves to make sure they are shifting properly. Each valve is equipped with a manual override in the event one should quit working. They are also equipped with an indicator light for each direction to show that they are being energized.



Once the motors are running the system can now be raised and lowered. The transmitter has a total of six buttons. There is a button for up for each jack, a button for lower for each jack and there are two buttons for controlling both jacks at the same time, one for up and one for down.



Travel with the wireless works in the same fashion as with the tethered pendants, refer to page E-2.

## Maintenance

### Hydraulic Oil

Oil in a hydraulic system performs the dual function of lubrication and transmission of power. Careful selection of oil should be made with the assistance of a reputable supplier, helping to ensure the satisfactory operation and life of this system and its components. Some factors important in selecting a good grade of hydraulic oil are:

- The oil must contain additives to insure high anti-wear characteristics.
- The oil must have proper viscosity to maintain sealing and lubricating qualities at the expected operating temperature of the hydraulic system.
- The oil must have rust and oxidation inhibitors for satisfactory system operation.

The manufacturer recommends the use of Mobil DTE 24 or its equivalent. Specifications for this oil are as follows.

### HYDRAULIC OIL

LSI SPEC NO	MILITARY SPEC NO	EQUIVALENT LUBRICANTS	SAE GRADE	MANUFACTURER
LU002	NOT AVAILABLE	TELLUS 32	10	SHELL AG
		VITAM GF 32	10	ARAL AG
		D. T. E. 25	10	MOBIL OIL AG
		RANDO HD-A	10	TEXACO

### Wheel Lubrication

The wheels on which this lift system moves are equipped with grease fittings on the hub of each wheel and should be greased monthly. Bearings should be filled with a good grade of EP (extreme pressure) grease.

To gain access to the grease fittings, the individual lifting units should be raised with a forklift and blocked up to allow you to move, remove to service the wheels.

#### Caution!

Care should be taken not to change the proper placement of any shims when moving or removing the wheel. Wheels must be shimmed snugly in place.

---

from the black pipe coupling in the reservoir. Wash in suitable solvent. Blow out with air from the inside out. When replacing the strainers, reverse the procedure above. Replace old oil drained with new.

### **Hydraulic Filter**

The hydraulic filter is in the top of the hydraulic reservoir. The filter housing is equipped with a filter condition indicator. When the indicator reads 20 inches of vacuum or more the filter should be replaced.

If there is a major failure of the pump, or other system components, the filter element should be replaced, as well as cleaning all the oil in the system and inside the reservoir.

- Pump the oil out of the reservoir into a suitable container.
- Wipe out the inside of the reservoir to remove all dirt.
- Pump oil back into the reservoir being sure to strain the oil through a 10-micron filter.

### **Operating temperatures**

This system has a wide range of operating temperatures. However, for temperatures below 32 degrees Fahrenheit (0 degrees Celsius) it is advisable to start the system and let it run to circulate the oil, which will warm it up. For prolong cold temperature usage a tank heater would be beneficial to keep the oil warm when the system is setting idle. Temperatures reaching 0 degrees Fahrenheit (-18 degrees Celsius), operation is not advisable unless the oil is designed to perform at these temperatures. Because of the type of duty cycle of the system heat is not normally a factor. However, the oil should never exceed 180 degrees Fahrenheit (82 degrees Celsius) which is where the oil can start to break down.

### **System Maintenance**

1. All hydraulic filters should be changed at least once a year.
2. Wheels and all bearings should be greased at least once a month with a good grade of high-pressure grease. This includes the wheel bearings and the steerable wheel mechanism thrust bearings if equipped.
3. Have a hydraulic oil sample tested once (general wear, metal and contaminated tests.) If high water content is suspected (milk in color with low lubricity), ask for the Carl Fischer method of water content tests.
4. Inspect hoses and gaskets for wear monthly and service as needed.
5. The cylinder manufacturer suggests that all cylinders be cycled once per week to keep all seals lubricated.
6. Use the maintenance on page 50 to keep a record of maintenance preformed.

---


## **Cylinder Packing Replacement Procedures**

Lift system has used various cylinders from various suppliers over the years. This is a task should not be attempted it at a job site. It is best to send the system back to the factory where we are fully equipped to service the cylinders. In addition, we are also equipped to load test the system when the re-sealing is complete. If you choose to take the cylinders to someone other than Lift Systems for resealing, make sure they are experienced with this type of cylinder and will stand behind the work they performed in the event there are problems.


If you choose to attempt this task yourself, you will first need to contact the factory for the replacement seals and information on the seal locations and procedures. You will need the system model number and serial number. You may be asked to provide the cylinder serial number.

## **Bleeding procedures for lifting units**


All units have the air bled out of them at the factory before test and shipment and should not need further bleeding once delivered. However, if air is somehow introduced into the system, the following methods may be used to bleed the system. The more current open cylinder gantries are equipped with bleeder screws in the rod seal glands and the small rod of the cylinders. The most effective method used to bleed these is to leave the cylinders retracted and apply very low pressure to the retract side of the cylinder and hold it there. While the pressure is being applied, turn the screw on the large gland counter-clockwise, just enough to where any air can escape from the screw and continue to do so until you have a steady flow of oil. Continue to do this with each bleed screw. This will eliminate most of the air; you may need to let the power unit set for a few hours to let any air that has mixed with the oil in the reservoir settle out. Otherwise you will pump the air right back into the cylinder. For any air that maybe trapped on the extend side of the cylinder It will work its way out when the cylinder is cycled a few times.




6. Remove this hose from here. This is the extend port which varies from machine to machine. On some systems this port is on the left hand side of the valve body. And the pilot and test port are on the right side.



7. And then reattach the hose to here.



8. Remove hose from here.



9. And reattach the hose to here.

## Maintenance Chart

**Problem: Not staging properly.**

Causes	Solutions
A. <b>Warning!</b> Severe side loading Very dangerous! System is out of level, runway track or floor could be settling.	A. Lower the load and reset properly.
B. Air in the cylinders	B. Bleed cylinders
C. Cylinder has internal bypass.	C. Reseal or replace cylinder.

**Problem: Electric Motor stalls when under load.**

Causes	Solutions
A. Pressure set to high	A. Pressure should be set to the highest pressure stated on the load chart.
B. Motor drawing too many amps due to a too long or too small of a cord.	B. Use shorter or heavier gauge cord.

**Problem: Circuit breaker keeps tripping.**

Causes	Solutions
A. Too long of cord	A. Use shorter cord
B. Gauge of cord too small.	B. Use heavier gauge cord.
C. Both units are plugged into the same circuit.	C. Make sure both units are on separate circuits
D. Pressure to high.	D. Reset pressure.

**Problem: Lift cylinder does not retract.**

Causes	Solutions
A. System pressure set too low.	A. Adjust relief valve. Consult factory.
B. Ruptured hose.	B. Check for oil leaking from hose and replace.
C. Safety holding valve at base of cylinder faulty.	C. Replace.
D. Pilot line from retract line to Safety-holding valve is plugged/restricted.	D. Replace pilot line.
E. Flow control is closed.	E. Open flow control.

### Testing a Cylinder for Bypass

There are two ways a cylinder can be checked for bypass the, first one listed below is the easiest. In addition, someone who has knowledge of hydraulics and how cylinders work should do this test. Done incorrectly, damage to the cylinder and injury may be possible.

1. Extend the cylinder an inch or two.
2. Disconnect the extend side of the twin line hose (this will be the male coupler on the base or the female on the power unit) then cap and plug off and pilot line going to the counter balance valve located on the bottom of the cylinder. On a self-contained system without couplers cap and plug the line going to the extend port.
3. Take a marker and make a mark on the chrome of the cylinder at the wiper.
4. Try to retract the cylinder and hold it there for one minute.
5. Watch the cylinder while it is in retract mode, if it extends even slightly there is oil bypassing the piston seals. The cylinder will need servicing. (However, a very small amount could be acceptable so please consult factory to determine what is acceptable. In addition, some brands of cylinders have cast iron piston rings, which will have some bypass and these require a different test. See step number six. Please consult the factory to determine which type you have.)
6. For cylinders with cast iron piston rings, you will need a flow meter that is good for ten to twenty gallons a minute.
7. Connect the twin line hose to the power unit and the base.
8. Connect the flow meter into the retract line, (this will be the female coupler on the base and the male coupler on the power unit) with the arrow pointing towards the power unit. This will read the return flow while the cylinder is extending.
9. Extend the cylinder.
10. When the cylinder reaches the end of its stroke and its maximum pressure setting, continue to hold it there and check the reading on the flow meter.
11. For the cylinders with cast iron piston rings, the reading should be no more than one gallon per minute. For piston with soft seals, the reading should be zero.
12. Now change the flow meter over to the extend line and make sure the arrow is pointing towards the power unit.
13. Retract the cylinder.

## Repair Section


### Steel wheel and bearing replacement

1. Items required
  - a.  $\frac{3}{4}$ " wrench
  - b. Dead blow hammer
  - c. Grease gun and multipurpose grease.
  - d. 9/16" Allen wrench for drain plug.
2. Since the 2020 and the 2033 models do not have wheels boxes, there is really only one safe way to replace them. First the hydraulic oil must be drained from the tank. It can either be pumped out or by using the drain plug.



3. Once the oil is removed lay the unit over onto its side with the wheels that are going to be replace upward. Be sure to put some sort of cribbing under the cylinder for support. You want to keep the top of the tank slightly raised so any remaining oil will not seep out from around the lid.


- With the wheel lying on its side, and the damaged race on the bottom side, use a brass bar to tap the race out of the wheel. It will be necessary to tap around the entire diameter of the bearing; do not try tapping just in one location as this will cause the race to become jammed.



- The simplest way to install the new race is to press it in with a small hydraulic press. Use a piece of round stock that is slightly smaller than the outer diameter of the race so that the tapered surface is not damaged. Press the race in until it is seated against the shoulder inside the wheel. If a press is not available, the race can be tapped in with a soft faced hammer of some kind until it is flush with the hub of the wheel, at this point use a piece of brass to tap the race in until it is seated against the shoulder. Use caution not to damage the tapered surface.
- Before inserting the new bearings, make sure, they have been packed with grease, either by using a bearing packer or by hand. Make sure to leave a thick coat of grease on the outer portion of the bearings. This will help hold the bearings in place.
- Take the wheel with the bearing and slide them in to the pocket. With the wheel in the pocket, lift so that the bottom spacers can be slid in.

## Cylinder removal

1. Items needed
  - a. Two (2) Pieces of #8 SAE male plug, Lift Systems # F131
  - b. One (1) piece of #4 SAE male plug, Lift System # F129
  - c. One (1) piece of #4 O-ring face cap Lift Systems # C51
  - d. One (1) piece of #4 O-ring face -plug Lift Systems # C52
  - e. One (1) piece of #6 O-ring face cap Lift Systems # C29
  - f. One (1) piece of #6 O-ring face plug Lift Systems # C33
  - g. Two (2) large wire ties
  - h. Two (2) 10" adjustable wrenches
  - i. External snap ring pliers for 1" pin
  - j. One (1) 3/4" socket with ratchet.
  - k. #3 Phillips screwdrivers.
2. Use the 1" external snap ring pliers to remove one of the snap rings from the header plate pin, have someone hold the header plate, slid the pin out, and then lift the header plate off.




3. Because pressure could be built up inside the cylinder, loosen up the bleed screws on the cylinder to help release that pressure. Use rags to wipe up the oil as it is coming out around the screws.


8. At the bottom of the cylinder disconnect the pilot line from the holding valve, cap the fitting with a #6 O-ring face cap, and plug the hose with a #6 O-ring face plug. Then disconnect the tee fitting from the holding valve, leaving the hoses attached to the tee, and cap the fitting with a #6 O-ring face cap and plug the hose with a #6 O-ring face plug.



9. Remove the small elbow fitting and plug the port with a #4 SAE male plug. Then remove the larger elbow and plug the port with a #8 SAE male plug.
10. Starting with the upper cylinder clamp remove the 4 four  $\frac{1}{2}$ " nuts and bolts.
11. Then remove the two bolts in the lower clamp and remove that half of the clamp.



12. Now remove the bolts at the bottom of the support arms and pull the support arms up and out. Two different size bolts have been used over the years the newest models us a  $\frac{3}{4}$ " bolt and the older models use a  $\frac{1}{2}$ " bolt. It may be necessary to pry the ends of the arms upward to get them out.



13. Make sure there is not any oil on the cylinder which could cause the sling to slip. If there is, clean it off. Wrap the 14' sling twice around the cylinder in a choker, making sure it is tightly wrapped around the cylinder. The factory has an eye that

## Replacing the A-line Counter balance Valve

1. Items required
  - a. 9/16" wrench
  - b. 1-1/8" wrench or 1-1/8" socket and ratchet.
  - c. Foot pound torque wrench.
2. Make sure the cylinder is fully retracted and not loaded. If it is not the cylinder will retract on its own once the counter balance is removed and there will be no way to control it.

### Warning!

**Do not ever remove the A-line counter balance valve with the cylinder extended or in a loaded condition. It will retract on its own and cannot be stopped once the counterbalance is removed.**

### Caution!

**The cartridges need to be properly set at the factory. If not supplied by the factory, the cartridge will not be properly adjusted and it may not hold the load.**


3. Using compressed air, blow any dirt or foreign particles out from the counterbalance cartridge.



Use compressed air to remove dirt from around the cartridge.

4. Use a 1-1/8" wrench, turn cartridge counter clockwise to remove it. Pull the cartridge out once it is completely unscrewed.
5. Occasionally the O-rings on the cartridge may roll off the cartridge during removal. If this happens, make sure the O-rings are not left in the valve body.

At times, these O-rings will roll off when removing the cartridge.



6. Insert new cartridge and turn it clockwise to tighten until the cartridge is seated. Then torque the cartridge to 30-35ftlbs.




5. Disconnect the hose.



6. Use 5/16" socket and ratchet and remove the four hose reel mounting bolts. Lift the reel off and set it on a bench.
7. Clamp the reel securely down on a workbench.
8. Put on a pair of work gloves, firmly grasp the hose, cut the wire ties, and slowly let the reel take up the hose. When the end of the hose clears the rollers, hold on to the drum of the reel and let it slowly, unwind until all the tension is off.
9. Unwrap the hose from the reel.
10. Using a 13/16" wrench disconnect the hose from the reel, plug hose and cap fitting with #6 flat face O-ring cap and plug.
11. Using a 7/16" socket and ratchet remove the clamp. Then remove the hose.


17. With the reel securely clamped to a bench, wrap all the hose around the reel.
18. With a firm grip, pull the hose so the reel turns with it. When the hose reaches the end, let it slowly return. The first time doing this, the reel should stop before all of the hose is taken up. Wrap the remaining hose around the reel and pull it out again. The reel needs to be tight. However, if the reel stops before all the hose is run out, then it is too tight. There should be one or two turns from that point.
19. With the hose wrapped on the reel and the tension set, run the hose through the rollers, leaving enough hose extended to go through the top plate of the lifting unit. Tie the hose off to the reel as was done with when removing the old reel.
20. Set reel back into lifting unit and bolt it back into place.
21. Attach the lower hoses of the lifting unit back on to the reel and tighten with a wrench.
22. If there is enough hose still extended, attach it to the fitting at the top of the cylinder. Do not tighten it until the wire ties have been cut loose. This will allow any twists in the hose to relax, and the hose should remain straight. Then tighten the hose.
23. If there isn't enough hose left extended, firmly grasp the hose and have someone cut the wire ties. Pull the hose upward and attach it to the fitting.
24. Start power unit, retract the cylinder, and hold it until it comes up to full pressure. At the same time have someone check for leaks. If leaks are found, stop and repair them. Repeat until full pressure is achieved. Then fully extend and retract the cylinder to verify the hose reel is working properly.




5. When the proper tension is achieved, tighten the four bolts.
6. To replace the motor, first it may be necessary to run the drive to get the chain's master link in a position, which provides easy access.
7. See Step #2
8. Loosen up the four bolts and back off the adjustment bolt. In addition, remove the master link in the chain so it can be removed.
9. Disconnect the hoses from the motor cap and plug the hoses and fittings with the #6 flat face caps and plugs. Make sure to tag or mark them so they can be put back in the correct locations.

## Replacing Bearings on Integral Drives

1. Items Required
  - a. Allen wrench set.
  - b.  $\frac{3}{4}$ " wrench or socket.
  - c. Pliers
  - d. 3/16" Allen driver for a ratchet.
  - e. 3/8" Allen driver for ratchet.
  - f. Torque wrench
2. The drive motor and mount will need to be removed, follow the instructions for replacing the motor but do not take the motor out of the motor mount, remove the mount with the motor in it.
3. With the drive motor removed, the mounting bolts for the drive box can be accessed.




4. Use a 3/8" hex driver to remove the bolts.
5. With the mounting bolts removed lift the unit up and off the drive box with a forklift.



10. With the axle out it will be possible to slide the wheels and bearings off the axle. There may be spacers between the wheels and bearings, keep track of where those spacers go. If just replacing the bearings the locking collars can be left in place.
11. Slide the new bearings, wheel, and spacers back onto the axle in the order they came off. If the pillow block bearing was removed and/or replaced, do not tighten the set screws until the bearing has been bolted down.
12. Set the axle back into the drive box, making sure the axle is centered and not protruding past either end of the box.
13. Install the bearing caps making sure to put them in the same location as they came out, snug the bolts with 3/16" Allen driver.
14. Torque the bearing cap bolts to 14ftlbs dry or 11ftlbs oiled.
15. Replace end caps.
16. Roll drive box over so it is upright and install back into lifting unit. It may be necessary to set the drive box on some blocks so it stays upright.
17. Set the unit back on to the drive box and install the mounting bolts.
18. Reinstall the drive motor as stated in the section for replacing the motor.

5. Pull the pump off the mount, the pump will have a drive coupling on its shaft. Before removing the coupling get a measurement from the pump to the end of the coupling and write it down. When the coupling is installed on the new pump, it must be set at the same dimension.



6. Install the coupling onto the new pump, setting it at the same dimension as the old one and tighten the set screw.
7. Before installing the pump, there is a rubber insert the goes between the coupling on the pump and the coupling on the motor, make sure this insert is in place before installing the pump.
8. Line up the coupling and insert the pump into the housing, then line the mounting holes making sure the small port is up and install the bolts and tighten.
9. Remove the fittings from the old pump and install them into the new pump, these are an O-ring type fitting and there is no need to use thread sealer.
10. If using a shop vacuum turn it back on and attach the hoses to the fittings and tighten.
11. If the tank was drained, refill the tank.


## Replacing or cleaning suction strainer

1. Items required
  - a. Pump with filters.
  - b. Large adjustable wrench or pipe wrench.
  - c. Pipe sealant.
  - d. 15/16" wrench.
  - e. 13/16" wrench.
  - f. Silicone sealant
  - g. Gasket material.
  - a. One (1) piece of #8 O-ring face cap Lift Systems # C30.
  - h. One (1) piece of #8 O-ring face plug Lift Systems # C34.
  - b. Three (3) piece of #6 O-ring face cap Lift Systems # C29.
  - i. Three (3) piece of #6 O-ring face plug Lift Systems # C33.
  - j. 1/2" and 9/16" wrench.

2. Using a 13/16" wrench disconnect the A, B and Pressure hose from the control valve and cap and plug the hoses and fittings.



3. Using the 1/2" or 9/16" wrench remove all the lid bolts and lift the lid off the tank.



4. If the oil is still usable pump it into a clean container but be sure to pump it through a 10-micron filter, this will filter out any particles that may be present in the oil. If the oil is not reusable then pump it into a waste container.


## Checking and Adjusting Operating Pressure

Normally the operating pressure does not require any adjusting. It is possible over time because of age and wear it may need to be slightly adjusted. In addition, the pressure should never be adjusted higher than the highest pressure called out on the load charts, doing so the system could be over loaded, which could cause damage to the system, injury, and/or death to personnel.


1. Items required
  - a. Standard Allen wrench set.
  - b. Small adjustable wrench.
2. Make sure the system does not have a load on it.
3. Start power unit.
4. With the system fully retracted, push and hold the retract button for that unit.
5. Read pressure on the gauge while the button is being held. The reading should be the highest pressure stated on the load charts.
6. To adjust, loosen the jam nut on the relief cartridge and turn the adjustment screw clockwise to increase and counter clockwise to decrease the pressure.




8. Remove the bleed screws.
9. Using a heavy-duty chain wrench such as the 36 inch Rigid Model C36, turn the desired gland counter clockwise. There could be as much as 1-5/8" of thread depending on the model of cylinder.
10. Due to the amount of press on the rod seals, once the threads are clear of each other the gland may not simply lift off.
11. Continue turning the gland, putting some upward force on it at the same time. This may help slide the gland upward and off the rod or sleeve.
12. If the gland will not slide off, use a soft face dead blow hammer and tap on the bottom edge of the gland, working the hammer around the full diameter of the gland.




13. With the gland off, remove old seals and thoroughly clean the gland with a cleaning solvent.
14. Inspect the gland for any rust that may have formed in the seal grooves and threads. Use a die grinder with a small wire wheel to clean off the rust.
15. Closely inspect the threads. If any rough spots are found, use the wire wheel to smooth them out. A rough spot in the threads could cause the gland to become stuck so tightly that it will have to be cut off.




19. Install the Poliak seal making sure the flat surface of the poly is up towards the top of the gland.



20. Before the wear band can be installed it will need to be cut to length. There should be  $1/16$ " gap between the ends of the wear band when is installed properly.
21. Install the wiper.




28. Once the gland is down on the sleeve and the seals are past the end of the gland take the chain wrench and turn the gland. At the same time, apply some downward pressure. The gland should slide down, settling into the sleeve into which it threads.
29. Carefully turn the gland until it starts to thread itself in. Continue turning the gland until it is fully threaded down and the shoulders of the gland and sleeve make contact.



30. When complete, reinstall the bleed screws, fittings and reconnect the hose.
31. Start the power and put the unit into retract. Check for leaks.
32. Slowly extend the cylinder and have someone open the bleed screws to remove any air in the cylinder.

8. If the gland will not slide off, use a soft face dead blow hammer and tap on the bottom edge of the gland, working the hammer around the full diameter of the gland.
9. With the small gland removed, the rod can be pulled out. However, it will be necessary to support the end of the rod to keep it level with the rest of the cylinder. An overhead crane or a jib works well for this.
10. Before the rod is completely removed, it is advised to catch the piston end either with a sling or by placing something under it that is soft enough not to damage the piston.



11. Repeat steps 6, 7, and 8 with the remaining sections. Make sure to place the rods and sleeves on something such as wood that will not scratch or damage them.
12. Starting with the barrel, thoroughly clean the inside with a cleaning solvent.
13. Thoroughly inspect the inner diameter of the barrel for damage or scratches. Small cosmetic scratches that cannot be felt are the result of normal wear. If any scratches that can be felt are found, the barrel will need to be honed.
14. Check the threads for any roughness. If roughness is found, use a die grinder with a wire wheel to smooth it out.(Use wire wheels only)
15. Clean up all dust particles created by the wire wheel.
16. Cover the end of the barrel to prevent damage and to keep it clean.
17. Remove old seals from the sleeves and rod, one at a time.
18. Thoroughly clean the sleeves, inside and out, with a cleaning solvent.
19. When one is thoroughly cleaned, inspect the inner diameter for scratches as with the barrel. Check the condition of the threads as was done with the barrel.
20. Inspect outside for chrome damage. Check for pitting, flaking, dents, and scratches. Cosmetic scratches are normal from wear and are acceptable. If there is any other damage, the item will need to be stripped, repaired, and re-chromed.
21. Continue until all sleeves and rods are cleaned and inspected.



30. Install the loader into the center groove; do not let the loader roll when installing it.




31. Before the piston buffer seal can be installed, it must be heated in an oven at 450 degrees for 20 minutes. A pizza oven works well for this.




32. Working quickly, while the seal is still hot, slip it over the piston and into the groove on top of the loader.

33. Using compressed air, blow cool air on the seal, working around the full diameter of the seal. This will cool and shrink the seal into the groove. The seal should be tight and it should not move or spin in the groove.


37. Place the wear ring in the groove and check the length; there should be 1/16" gap between the ends. The ends of the wear ring must be chamfered as shown.



38. Using Loctite 380 instant adhesive spread a thin coat over the wear ring groove as shown.




39. Place the wear ring material in the grooves and hold them in place by using zip ties. It will take 30 to 60 minutes for the adhesive to dry.




40. Prep the remaining pistons by following the above steps.

41. After the pistons are complete then the glands can be prepped.



45. Before the wear band can be installed it will need to be cut to length. There should be 1/16" gap between the ends of the wear band when it is installed.

46. Install the wiper.




47. Prep the rest of the glands in the same manner as above.

48. Take the barrel and coat the first six inches of the inner diameter of the barrel with a heavy oil.



51. The factory has special compression rings for compressing the seals so that the sleeve can be inserted into its mating part. This ensures that damage does not occur to the seals or to the threads of the mating part. It is advisable to create a similar device.




52. Slowly and carefully push the sleeve into its mating part.

55. When the end of the sleeve makes contact with the first rod seal, the gland will become tight. Using a dead blow hammer, tap the top of the gland to work it onto the sleeve. **Do not use a steel hammer.**
56. Once the gland is past the end of the sleeve use a dead blow hammer and something such as a piece of nylon to drive the gland down the sleeve. **Do not use steel.**



57. As the gland reaches its mating part, stop before it makes any contact. Check the level of the sleeve to ensure it is level with its mating part. The two parts have to be level with each other in order for the gland to be threaded in.
58. Put heavy oil on the outer seals of the gland and anti-seize on the threads.
59. Carefully tap the gland into its mating part, stopping just before the threads of both parts make contact.



60. Using the chain wrench, slowly turn the gland clockwise, simultaneously applying a small amount pressure towards the mating part until the threads are engaged.
61. Continue slowly turning the gland until it is fully seated.
62. Repeat steps 48 through 60 with the remaining sleeves and rods.

**OPTIONS****Level-Lift System**

The unique design of the Level-Lift system puts accurate information instantly at the operator's fingertips. The sensor(s) will transfer information on the horizontal level of the load directly to the readout. Load corrections can be made immediately, front to back, as well as side to side.

The Level-Lift system consists of three (3) main components packaged in a handsome carrying case for easy storage and mobility. The interior of the case is custom fit to the Level-Lift components giving durable and safe transport from job to job. All components are calibrated and tested at the factory.

For set-up, calibrations, and use of the Level-Lift system, please refer to the instruction manual provided in each carrying case.

**Propels**

Lift Systems offers three propel options, Cylinder type, Pin on hydrostatic drive, and Integral. Follow the instructions for the specific propel option with which your lifting units are equipped.

**Warning!**

Never propel with a load that is raised more than is required for clearance. The higher the load the less stable the system.

**Using the Propels****1) Cylinder type.**

- a) Pin the cylinder onto the two ears located just below the quick couplers using the 7/8" x 6-1/2 hitch pin supplied.
- b) Using the 7/8" and 4 1/2" hitch pin connect the propel shoe to the rod of the cylinder. The runners of the shoe should sit on the center rail of the track.
- c) Connect the hoses of the cylinder to the right hand couplers on the base.

## Integral Drives

As with the pin on drive you must also shift the selector to Propel. However, for free-wheeling there is an additional valve that must be shifted to free wheel the drive when lifting or lowering the load.

## Side Shifts

Lift Systems offers four types of side shifts or "Trolley" systems.

- 1) Cylinder type with slider pad dolly.
- 2) Cylinder type with wheeled dolly.
- 3) Continuous Hydrostatic drive with wheeled dolly.
- 4) Continuous chain drive with wheeled dolly.

If you order a side shift system instructions specific to that system will be included at the end of this section.

Side shift or "Trolley" systems allow safe movement of the load latitudinally, or perpendicular to the direction of movement of the lifting units. Due to stability and capacity factors, the capacity of the system is de-rated by a minimum of 40% when using side shift systems. As with all other phases of the lift plan, a professional engineer should be consulted regarding the use of side shifts or "Trolleys".


### Warning!

**Always move slowly and smoothly when using side shift or "Trolley" systems. The inertia of a rapidly moving load may exceed the stability of the lifting units causing loss of the load and possible injury or death to personnel.**


### Warning!

**The header beam should never be more than  $\frac{1}{2}$ " of level over a 20ft. span.**


**PARTS**




2020SC WITH DRIVE OPTION



1. DV86	Control Valve
2. MG05	Pressure Gauge
3. RV029	Relief Valve (set at 1800psi)
4. MVP100	Sub plate
5. FCV34	Flow Control, control retract speed
6. HF22	Return Filter(FE24 Replacement element)
7. FB02	Filler Breather (older systems)
a. FB11	Filler Breather on newer systems.
8. MG36	Dirty filter gauge




1. FCV20      Needle valve for speed control on drive option




2. ST12      Suction strainer  
3. MG01      oil level gauge




4. HM22      Drive motor




1. PRP09 Hub
2. W02 Press on tire
3. MP188 Ratchet jack




4. P63 Pump
5. HR11 Hose reel



1. MJREM01 CONTROL BOX (This box is used on 110/220volt systems.)
2. S50 ON/OFF SWITCH
3. ME251 PENDANT CONNECTOR
4. ME640 CORD
5. ME641 PLUG



When ordering cylinder seals, you must have the cylinder serial number, over time the part numbers for the seals may have changed.



**MSDS****MATERIAL SAFETY DATA SHEET****RILCO****RILCO Premium AW Hydraulic Oil (all grades)**

Date of Preparation: March 23, 2013

**SECTION 1: CHEMICAL PRODUCT AND COMPANY IDENTIFICATION***Product Name:* RILCO Premium AW (all grades)*Chemical Family:* Blend*Manufactured for:* RILCO Oil Company, Inc.

1320 1st St

Rock Island, IL 61201

**EMERGENCY TELEPHONE NUMBERS:**

RILCO Oil Company, Inc. (309) 788-5631 Normal Business Hours

(800) 779-6456 After Business Hours

**SECTION 2: COMPOSITION/INFORMATION AND INGREDIENTS****Chemical Ingredient**

Base Lubricating Oil 95-99%

Proprietary Additives 1-5%

**SECTION 3: HAZARD IDENTIFICATION****EMERGENCY OVERVIEW:** *Oil mist, if generated.*

HMIS Hazard Rating

H 1

F 1

R 0

**US OSHA HAZARD COMMUNICATION STANDARD:** Product assessed in accordance with OSHA 29 CFR 1910.1200 and determined not to be hazardous.**Potential Health Effects:***Inhalation:* Vapor pressure is very low. Vapor inhalation under ambient conditions is normally not a problem.*Eye Contact:* Expected to be minor eye irritant.*Skin Contact:* Repeated or prolonged skin contact may cause dermatitis.*Ingestion:* Not expected to be acutely toxic.*Chronic:* None known.

MSDS RILCO Premium AW Hydraulic Oil

---

**SECTION 10: STABILITY AND REACTIVITY**

---

*Stability:* Stable under normal temperatures and pressures.

*Conditions to Avoid:* None known

*Materials to Avoid:* Strong oxidizing agents.

---

**SECTION 11: TOXICOLOGICAL INFORMATION**

---

*Oral Toxicity (rats):* Practically non-toxic (LD50: greater than 2000 mg/kg.)

*Dermal Toxicity (rabbits):* Practically non-toxic (LD50: greater than 2000 mg/kg.)

*Inhalation Toxicity (rats):* Practically non-toxic (LC50: greater than 5 mg/l).

*Eye Irritation (rabbits):* Practically non-irritating. (Draize score: greater than 6 but 15 or less.)

*Skin Irritation (rabbits):* Practically non-irritating. (Primary Irritation Index: greater than 0.5 but less than 3.)

---

**SECTION 12: ECOLOGICAL INFORMATION**

---

*Ecotoxicity:* No data available.

---

**SECTION 13: DISPOSAL CONSIDERATIONS**

---

*Regulatory Information:* All disposals must comply with federal, state and local requirements.

---

**SECTION 14: TRANSPORTATION INFORMATION**

---

*U.S. Department of Transportation (DOT)*

*Highway/Rail (Bulk):* Not Regulated

*Highway/Rail (Non-Bulk):* Not Regulated

---

**SECTION 15: REGULATORY INFORMATION**

---

*TSCA:* This material is in compliance with the Toxic Substances control Act (15 USC 2601-2629) and is listed in the TSCA Inventory.

Hazard Categories for SARA 311/312 Reporting:

Health Immediate (Acute) No

Health Delayed (Chronic) No

Physical Fire No

Physical Sudden Release of Pressure No

Physical Reactive No

Physical Nuisance Mist/Dust Only No

01=SARA 313

11=NJRTK

21=TSCA Sect 5(a)(2)

02=MASS RTK

12=CERCLA 3024

22=TSCA Sect 6

03=NTP Carcinogen

13=MN RTK

23=TSCA Sect 12 (b)

## Material Safety Data Sheet

Shell Gadus S3 V220C 2  
MSDS# 18078  
Version 1.3  
Effective Date 02/05/2014

According to OSHA Hazard Communication Standard, 29 CFR  
1910.1200

## 1. MATERIAL AND COMPANY IDENTIFICATION

Material Name : Shell Gadus S3 V220C 2  
Product Code : 001D8425  
Uses : Automotive and industrial grease.

Manufacturer/Supplier : SOPUS Products  
PO BOX 4427  
Houston, TX 77210-4427  
USA

SDS Request : 877-276-7285

Emergency Telephone Number  
Spill Information : 877-242-7400  
Health Information : 877-504-9351

## 2. COMPOSITION/INFORMATION ON INGREDIENTS

Chemical Identity	CAS No.	Concentration
Asphalt, fumes	8052-42-4	1.00 - 5.00 %

A lubricating grease consisting of highly-refined mineral oil and additives.  
The highly refined mineral oil contains <3% (w/w) DMSO-extract, according to IP346.

## 3. HAZARDS IDENTIFICATION

Emergency Overview	
Appearance and Odour	: Red. Semi-solid at ambient temperature. Slight hydrocarbon.
Health Hazards	: High-pressure injection under the skin may cause serious damage including local necrosis.
Safety Hazards	: Not classified as flammable but will burn.
Environmental Hazards	: Harmful to aquatic organisms, may cause long-term adverse effects in the aquatic environment.

Health Hazards	: Not expected to be a health hazard when used under normal conditions.
Health Hazards Inhalation	: Under normal conditions of use, this is not expected to be a primary route of exposure.
Skin Contact	: Prolonged or repeated skin contact without proper cleaning can clog the pores of the skin resulting in disorders such as oil acne/folliculitis.
Eye Contact	: May cause slight irritation to eyes.
Ingestion	: Low toxicity if swallowed.
Other Information	: High-pressure injection under the skin may cause serious damage including local necrosis. Used grease may contain harmful impurities.

Shell Gadus S3 V220C 2  
MSDS# 18078  
Version 1.3  
Effective Date 02/05/2014

**Material Safety Data Sheet**

According to OSHA Hazard Communication Standard, 29 CFR  
1910.1200

<b>Flammability or Explosion limits</b>	:	> 320 °C / 608 °F
<b>Auto ignition temperature</b>	:	
<b>Specific Hazards</b>	:	Hazardous combustion products may include: A complex mixture of airborne solid and liquid particulates and gases (smoke). Carbon monoxide may be evolved if incomplete combustion occurs. Unidentified organic and inorganic compounds.
<b>Suitable Extinguishing Media</b>	:	Foam, water spray or fog. Dry chemical powder, carbon dioxide, sand or earth may be used for small fires only.
<b>Unsuitable Extinguishing Media</b>	:	Do not use water in a jet.
<b>Protective Equipment for Firefighters</b>	:	Proper protective equipment including breathing apparatus must be worn when approaching a fire in a confined space.

---

**6. ACCIDENTAL RELEASE MEASURES**

Avoid contact with spilled or released material. For guidance on selection of personal protective equipment see Chapter 8 of this Material Safety Data Sheet. See Chapter 13 for information on disposal. Observe the relevant local and international regulations.

<b>Protective measures</b>	:	Avoid contact with skin and eyes. Use appropriate containment to avoid environmental contamination. Prevent from spreading or entering drains, ditches or rivers by using sand, earth, or other appropriate barriers.
<b>Clean Up Methods</b>	:	Shovel into a suitable clearly marked container for disposal or reclamation in accordance with local regulations.

---

**7. HANDLING AND STORAGE**

<b>General Precautions</b>	:	Use local exhaust ventilation if there is risk of inhalation of vapours, mists or aerosols. Use the information in this data sheet as input to a risk assessment of local circumstances to help determine appropriate controls for safe handling, storage and disposal of this material.
<b>Handling</b>	:	Avoid prolonged or repeated contact with skin. Avoid inhaling vapour and/or mists. When handling product in drums, safety footwear should be worn and proper handling equipment should be used. Properly dispose of any contaminated rags or cleaning materials in order to prevent fires.
<b>Storage</b>	:	Keep container tightly closed and in a cool, well-ventilated place. Use properly labelled and closeable containers. Store at ambient temperature.
<b>Recommended Materials</b>	:	For containers or container linings, use mild steel or high density polyethylene.
<b>Unsuitable Materials</b>	:	PVC.
<b>Additional Information</b>	:	Polyethylene containers should not be exposed to high temperatures because of possible risk of distortion.

Shell Gadus S3 V220C 2  
MSDS# 18078  
Version 1.3  
Effective Date 02/05/2014

According to OSHA Hazard Communication Standard, 29 CFR  
1910.1200

## Material Safety Data Sheet

Check with respiratory protective equipment suppliers. Where air-filtering respirators are suitable, select an appropriate combination of mask and filter. Select a filter suitable for combined particulate/organic gases and vapours [boiling point >65°C(149 °F)].

### Hand Protection

Where hand contact with the product may occur the use of gloves approved to relevant standards (e.g. Europe: EN374, US: F739) made from the following materials may provide suitable chemical protection: PVC, neoprene or nitrile rubber gloves. Suitability and durability of a glove is dependent on usage, e.g. frequency and duration of contact, chemical resistance of glove material, dexterity. Always seek advice from glove suppliers. Contaminated gloves should be replaced. Personal hygiene is a key element of effective hand care. Gloves must only be worn on clean hands. After using gloves, hands should be washed and dried thoroughly. Application of a non-perfumed moisturizer is recommended. For continuous contact we recommend gloves with breakthrough time of more than 240 minutes with preference for > 480 minutes where suitable gloves can be identified. For short-term/splash protection we recommend the same, but recognise that suitable gloves offering this level of protection may not be available and in this case a lower breakthrough time may be acceptable so long as appropriate maintenance and replacement regimes are followed. Glove thickness is not a good predictor of glove resistance to a chemical as it is dependent on the exact composition of the glove material. Glove thickness should be typically greater than 0.35 mm depending on the glove make and model.

### Eye Protection

Wear safety glasses or full face shield if splashes are likely to occur.

### Protective Clothing

Skin protection not ordinarily required beyond standard issue work clothes.

### Monitoring Methods

Monitoring of the concentration of substances in the breathing zone of workers or in the general workplace may be required to confirm compliance with an OEL and adequacy of exposure controls. For some substances biological monitoring may also be appropriate. Validated exposure measurement methods should be applied by a competent person and samples analysed by an accredited laboratory. Examples of sources of recommended exposure measurement methods are given below or contact the supplier. Further national methods may be available.

National Institute of Occupational Safety and Health (NIOSH), USA: Manual of Analytical Methods <http://www.cdc.gov/niosh/>  
Occupational Safety and Health Administration (OSHA), USA: Sampling and Analytical Methods <http://www.osha.gov/>  
Health and Safety Executive (HSE), UK: Methods for the Determination of Hazardous Substances <http://www.hse.gov.uk/>

Shell Gadus S3 V220C 2

MSDS# 18078

Version 1.3

Effective Date 02/05/2014

According to OSHA Hazard Communication Standard, 29 CFR  
1910.1200

## Material Safety Data Sheet

Unless indicated otherwise, the data presented is representative of the product as a whole, rather than for individual component(s).

- Acute Oral Toxicity** : Expected to be of low toxicity: LD50 > 5000 mg/kg , Rat
- Acute Dermal Toxicity** : Expected to be of low toxicity: LD50 > 5000 mg/kg , Rabbit
- Acute Inhalation Toxicity** : Not considered to be an inhalation hazard under normal conditions of use.
- Skin Irritation** : Expected to be slightly irritating. Prolonged or repeated skin contact without proper cleaning can clog the pores of the skin resulting in disorders such as oil acne/folliculitis.
- Eye Irritation** : Expected to be slightly irritating.
- Respiratory Irritation** : Inhalation of vapours or mists may cause irritation.
- Sensitisation** : Not expected to be a skin sensitiser.
- Repeated Dose Toxicity** : Not expected to be a hazard.
- Mutagenicity** : Not considered a mutagenic hazard.
- Carcinogenicity** : Not expected to be carcinogenic. Product contains mineral oils of types shown to be non-carcinogenic in animal skin-painting studies. Highly refined mineral oils are not classified as carcinogenic by the International Agency for Research on Cancer (IARC).

Material	Carcinogenicity Classification
Highly refined mineral oil (IP346 <3%)	ACGIH Group A4: Not classifiable as a human carcinogen.
Highly refined mineral oil (IP346 <3%)	IARC 3: Not classifiable as to carcinogenicity to humans.
Highly refined mineral oil (IP346 <3%)	GHS / CLP: No carcinogenicity classification

- Reproductive and Developmental Toxicity** : Not expected to be a hazard.
- Additional Information** : Used grease may contain harmful impurities that have accumulated during use. The concentration of such harmful impurities will depend on use and they may present risks to health and the environment on disposal. ALL used grease should be handled with caution and skin contact avoided as far as possible. High pressure injection of product into the skin may lead to local necrosis if the product is not surgically removed.

## 12. ECOLOGICAL INFORMATION

Ecotoxicological data have not been determined specifically for this product. Information given is based on a knowledge of the components and the ecotoxicology of similar products. Unless indicated otherwise, the data presented is representative of the product as a whole, rather than for individual component(s).

- Acute Toxicity** : Poorly soluble mixture. May cause physical fouling of aquatic organisms. Expected to be harmful: LL/EL/EL50 10-100 mg/l (to aquatic organisms) LL/EL50 expressed as the nominal amount

**Material Safety Data Sheet**

Shell Gadus S3 V220C 2  
MSDS# 18078  
Version 1.3  
Effective Date 02/05/2014  
According to OSHA Hazard Communication Standard, 29 CFR  
1910.1200

**Federal Regulatory Status****Notification Status**

EINECS	All components listed or polymer exempt.
TSCA	All components listed.
DSL	All components listed.

**Comprehensive Environmental Release, Compensation & Liability Act (CERCLA)**

Shell Gadus S3 V220C 2 () Reportable quantity: 37 lbs

Zinc compounds, NOS (25103-54-2)

Asphalt, fumes (8052-42-4) Reportable quantity: 100 lbs

Shell classifies this material as an "oil" under the CERCLA Petroleum Exclusion, therefore releases to the environment are not reportable under CERCLA.

The components with RQs are given for information. Under Section 311 of the Clean Water Act (CWA) this material is considered an oil. As such, spills into surface waters must be reported to the National Response Center at (800) 424-8802.

**SARA Hazard Categories (311/312)**

No SARA 311/312 Hazards.

**SARA Toxic Release Inventory (TRI) (313)**

Zinc compounds, NOS (25103-54-2) 2.70%

**State Regulatory Status****California Safe Drinking Water and Toxic Enforcement Act (Proposition 65)**

This material does not contain any chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

**New Jersey Right-To-Know Chemical List**

Zinc compounds, NOS (25103-54-2) 2.70%

Listed.

Asphalt, fumes (8052-42-4) 2.00%

Listed.

## FORMS

## Pre-Lift Planning Checklist

**Project Data**

Project:
Project Number:
Client/Owner:
Date of Lift:
Location of Lift:
Description of Lift:
Number of Gantry legs used:

**Lift Type**

Straight Up and Down:
Straight Up and Down with travel:
Stand up and Lay over:
Straight up and down w/ Side shifting:
Multiple beam lifts:
Load on top of header beams:
Combination lifts:
Other:

**Lifted Load Data**

Description:
Weight
How was weight determined:
Weight was determined by whom:

**Load center of Gravity is:**

Centered:
Off-centered:

**Lifting component data**

Component	Capacity	Deadweight
Link Links		
Header beams		
Slings		
Shackles		
Special lifting devices		

**Total calculated load:**

Prepared by:	Date:
Lift Planner Signoff:	Date:
Project Manager Signoff:	Date:

**Maximum calculated load per gantry leg:****Gantry Data**

Gantry model:
Serial number:
Manufacturer:
Number of stages:
Gantry weight:

**Gantry is:**

Externally propelled:
Self propelled:

**Gantry support surface:**

Concrete floor on grade:
Elevated floor:
Hardwood timber mats:
Softwood timber mats:
Crib stack:
Soil:
Other:

Have calculated bearing pressures been checked against allowable pressures on bearing surfaces?  Yes  NO

**Gantry system configuration:**

Gantry will begin lift in what stage:
Gantry will finish lift in what stage:
Any special lifting devices:
Header beam span:
Loading point(s):

**Rated capacity per gantry leg:****Maximum calculated load per gantry leg as percent of rated capacity:**

Open Cylinder Gantry Annual Inspection Checklist					
Owner/User:		Model #	Serial #		
Service Status:	Date:	Technician:			
Status: <input type="checkbox"/> = Satisfactory <input checked="" type="checkbox"/> = Deficiency <input type="checkbox"/> = Recommendation <input type="checkbox"/> N/A = Does not Apply					
Item No	Item	Status	Item No		
			Right Hand Power Unit		
Historical Data			General		
1	Current Annual Inspection		38	Tagged with weight & capacity	
2	Maintenance Records		39	Leaks	
3	Repair/Modification Records		40	Pressure Settings	
4	Load Test Reports		41	Controls Identified	
5	Other		42	Instruments/Gauges	
General			43	Welds	
6	Sheet Metal		44	Hydraulic Oil Leaks	
7	Guard/Covers		45	Decals	
8	Housekeeping		46	Load Charts	
9	Safety/Warning Decals		47	Performance	
10	Corrosion		48	Exhaust System	
11	Hydraulic Oil Leaks		49	Belt/Hoses	
12	Hours		50	Guards/Covers	
13	Other		51	Coolant	
Left Hand Power Unit			52	Engine Oil	
14	Tagged with weight & capacity		53	Air Filter	
15	Leaks		54	Oil Filter	
16	Pressure Settings		55	Fuel Filter	
17	Controls Identified		56	Engine Mounts	
18	Instruments/Gauges		57	Hydraulic Filters	
19	Welds		58	Couplers	
20	Hydraulic Oil Leaks		59	Electrical Components	
21	Decals		60	Electrical Connectors	
22	Load Charts		61	Other	
23	Performance		Base #1		
24	Exhaust System		62	Tagged with weight & capacity	
25	Belt/Hoses		63	Cylinder Leaks	
26	Guards/Covers		64	Cylinder Seals	
27	Coolant		65	Welds	
28	Engine Oil		66	Hoses	
29	Air Filter		67	Selector Valve	
30	Oil Filter		68	Hydraulic Leaks	
31	Fuel Filter		69	Level and Plumb	
32	Engine Mounts		70	Counter Balance Settings	
33	Hydraulic Filters		71	Safety Relief Settings	
34	Couplers		72	Decals	
35	Electrical Components		73	Header Plates	
36	Electrical Connectors		74	Header Pins	
37	Other		75	Wheel Bearings Greased	
			76	Couplers	
			77	Other	



