


# Electric Power Bar | 8,000 Lbs.



## **Technical Data/Specifications**

### **Drive Wheel**

#### **Motor Characteristics**

Current Free Running . . . . . . . . . . . . . . . 5 Amp 

### **Cautions**

- Push the load forward ONLY. Pulling under load will cause damage.
- Use 50' or less of drop cord with a 12 gauge or larger, on at least a 20 amp circuit.
- Do not set load on top of the body only use the (two) tongue options, to bite for leverage.
- For positioning loads only. Reverse direction on switch is only to back unit after final positioning.
- Change Direction (forward or reverse) ONLY after power bar has come
- Failure to comply with these cautions will result in significant damage to internal components.



